

Installation and Operating instructions for

# **C9900-P208 and C9900-P209**

Power Supply Units

Version: 1.5

Date: 2012-02-22

**BECKHOFF**



# Table of contents

<b>1. Foreword</b>	<b>2</b>
Notes on the Documentation	2
Liability Conditions	2
Trademarks	2
Patent Pending	2
Copyright	2
State at Delivery	2
Delivery conditions	2
Description of safety symbols	3
Basic safety measures	4
Operator's obligation to exercise diligence	4
<b>2. Product Description</b>	<b>5</b>
Appropriate Use	5
Beckhoff power supply technology	5
Electrical data	6
<b>3. Installation Instructions</b>	<b>7</b>
Configuration and installation	7
Connection with the motherboard	8
Pin assignment of the pin strips	8
Connection with the Industrial PC	9
Pin assignment of the connector	9
Preparing the cable harness	10
External wiring	10
Cable Cross Sections	10
Power supply of the Industrial PC	11
Configuration for shutting down the PC	11
PC_ON and Power Status functions	11
UPS output, C9900-P209 only	12
UPS output function	12
Wiring diagram	13
Installation of the supply cables	14
Connector installation	14
<b>4. Operating Instructions</b>	<b>15</b>
UPS Software Components (only C9900-P209)	15
Installation on the PC	15
Help files	15
Servicing	15
Shutting down	15
Disposal	15
<b>5. Assembly dimensions</b>	<b>16</b>
<b>6. Troubleshooting</b>	<b>17</b>
Beckhoff Support & Service	17
Beckhoff branches and partner companies	17
Beckhoff Headquarters	17
Beckhoff Support	17
Beckhoff Service	17
<b>7. Appendix</b>	<b>18</b>
Technical data	18
Approvals	18
FCC: Federal Communications Commission Radio Frequency Interference Statement	18
FCC: Canadian Notice	18

# Foreword

## Notes on the Documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards. It is essential that the following notes and explanations are followed when installing and commissioning these components.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

## Liability Conditions

The documentation has been prepared with care. The products described are, however, constantly under development. For that reason the documentation is not in every case checked for consistency with performance data, standards or other characteristics. In the event that it contains technical or editorial errors, we retain the right to make alterations at any time and without warning. No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

## Trademarks

Beckhoff®, TwinCAT®, EtherCAT®, Safety over EtherCAT®, TwinSAFE® and XFC® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

## Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents:

EP1590927, EP1789857, DE102004044764, DE102007017835

with corresponding applications or registrations in various other countries.

The TwinCAT Technology is covered, including but not limited to the following patent applications and patents:

EP0851348, US6167425 with corresponding applications or registrations in various other countries.

## Copyright

© Beckhoff Automation GmbH.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

## State at Delivery

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH.

## Delivery conditions

In addition, the general delivery conditions of the company Beckhoff Automation GmbH apply.

## Description of safety symbols

The following safety symbols are used in this operating manual. They are intended to alert the reader to the associated safety instructions.

 <b>DANGER</b>	<b>Acute risk of injury!!</b> If you <b>do not</b> adhere the safety advise adjoining this symbol, there is immediate danger to life and health of individuals!
 <b>WARNING</b>	<b>Risk of injury!</b> If you <b>do not</b> adhere the safety advise adjoining this symbol, there is danger to life and health of individuals!
 <b>CAUTION</b>	<b>Hazard to individuals!</b> If you <b>do not</b> adhere the safety advise adjoining this symbol, there is obvious hazard to individuals!
 <b>Attention</b>	<b>Hazard to devices and environment</b> If you <b>do not</b> adhere the notice adjoining this symbol, there is obvious hazard to materials and environment.
 <b>Note</b>	<b>Note or pointer</b> This symbol indicates information that contributes to better understanding.

## Basic safety measures

	<p><b>Use only with Beckhoff Industrial PCs</b></p>
<p><b>Note</b></p>	<p>The power supply unit must only be used in conjunction with Beckhoff Industrial PCs!</p>
	<p><b>Switch off the power supply of the system during installation!</b></p>
<p><b>Attention</b></p>	<p>During assembly, removal and electrical wiring of the power supply unit, the power supply of the system must be switched off in order to prevent damage on the power supply unit and the Industrial PC. Items of equipment that have been switched off must be secured against being switched on again.</p>
	<p><b>Do not open the power supply unit while voltage is applied!</b></p>
<p><b>WARNING</b></p>	<p>The supply voltage must be switched off before the power supply unit housing is opened.</p>

## Operator's obligation to exercise diligence

	<p><b>Only appropriately trained staff may install the power supply unit!</b></p>
<p><b>CAUTION</b></p>	<p>The operator must ensure that only appropriately trained electricians deal with installation and wiring of the power supply unit.</p>

# Product Description

## Appropriate Use


The C9900-P208 and C9900-P209 power supply unit provide the power supply for Beckhoff Industrial PCs.

The C9900-P209 power supply in conjunction with a C9900-U330 battery pack allows the construction of an uninterruptible power supply (UPS).

 <b>WARNING</b>	<p><b>Risk of explosion!</b></p> <p>Risk of explosion if other battery packs are used!</p>
---	--

## Beckhoff power supply technology

Schematic diagram of power supply unit wirings



Innovative solution for shutting down Industrial PCs

Industrial PCs equipped with a UPS are in actual use frequently switched off by simply turning off the supply voltage. In this case the PC shuts down via the battery. However, over time this reduces the service life of the battery.

The new Beckhoff power supply technology approach addresses this problem and now offers the user the option of switching the PC off without the need for using the battery, thereby reducing the load on the battery.

In addition to the main switch this innovative solution uses an ON/OFF switch for the machine. Basically, the main switch remains switched on and provides the power supply for the PC during shutdown. Via the PC ON-input of the power supply the PC gets the command to shut down the operating system.

Once the PC has shut down, the PC power supply unit sets the Power Status-output (P-S) to 0, what indicates that the process is complete and that the main voltage can be switched off. This can be done manually via a signal lamp connection or via a contactor. With this solution the main switch generally only has to be switched off if the control cabinet has to be opened. The battery will only be used in the event of a power failure.

In order to maintain a screen display for the Industrial PC in the event of a power failure, the C9900-P209 power supply unit is equipped with a UPS output 27 V / 1.4 A for connecting a Control Panel with a display dimension up to 19 inches. This enables a power failure to be visualized and displayed to the user. Once the PC has shut down, the UPS output is switched off.

For a detailed functional description please refer to section [External wiring](#).

## Electrical data

**Input voltage:** 22-30V DC/ 15A  
**Power output:** 250W (max.)

<b>Output voltages:</b>	+ 5V	14A
	+ 12V	12A
	+ 3.3V	12A
	- 5V	0.3A
	- 12V	0.5A
	+ 5VSB	1.5A

# Installation Instructions

## Configuration and installation

View of the power supply unit




The power supply unit is installed at the prescribed position in the Industrial PC.

The supply connections for the power supply unit are located next to the fan (1). The electrical connections for the motherboard are on the opposite side (2).

## Connection with the motherboard

Pin strips on the output side



Connection with the motherboard

The power supply unit is connected with the motherboard according to the installation instructions of the board.

Connection	Function
1	ATX interface
2	5V/12V supply
3	POWER ON
4	COM interface
5	12V supply

### Pin assignment of the pin strips

ATX DC output



Pin	Function	Pin	Function
1	3.3V	11	3.3V
2	3.3V	12	- 12V
3	GND	13	GND
4	+ 5V	14	PS ON
5	GND	15	GND
6	+ 5V	16	GND
7	GND	17	GND
8	PWR OK	18	- 5V
9	5VSTB	19	+ 5V
10	12V	20	+ 5V

5V/ 12V supply for drives



Pin	Function	Pin	Function
1	+ 12V	5	+ 12V
2	GND	6	GND
3	GND	7	GND
4	+ 5V	8	+ 5V

POWER ON



Pin	Function
1	POWER-ON
2	POWER-ON

COM interface (RS 232)



Pin	Function
3	TXD
5	RXD
9	GND

ATX 12V DC-Output




Pin	Function	Pin	Function
1	GND	3	+ 12V
2	GND	4	+ 12V

## Connection with the Industrial PC

The power supply unit features an 8-pin contact strip for connecting the power supply unit inside the Industrial PCs with the respective connection sockets for power supply switch and battery pack (C9900-P209 only).

In addition, the C9900-P209 power supply unit features a UPS output for connecting a Control Panel.



 <b>Note</b>	<p><b>Uninterruptible power supply (UPS)</b></p> <p>With the C9900-P209 power supply you can realize an uninterruptible power supply (UPS) using the battery pack C9900-U330.</p>
---	---

 <b>WARNING</b>	<p><b>Risk of explosion!</b></p> <p>Risk of explosion if other battery packs are used!</p>
---	--

A Control Panel can be connected to the UPS output of the C9900-P224. The maximum current loading is 1.4 A.

### Pin assignment of the connector

The power supply and the external circuit for switching the Industrial PC on and off are connected via the plug connector.

Pin assignment for connecting the switch, the power supply and the battery pack (optional)

Input 24V DC:

Pin	Function
1	- Battery Pack (C9900-P209 only)
2	+
3	⊖
4	- 24 V DC Power Supply
5	+
6	Power-Status
7	PC_ON

Pin assignment for connecting a control panel (optional)

UPS-output (C9900-P209 only):


Pin	Function
1	UPS- UPS-output
2	UPS+

### Preparing the cable harness

A wiring harness is used for connecting the power supply unit with the connection sockets in the Industrial PC. Due to different cable lengths, the harness is produced individually for each type of computer.

The wiring diagram section shows the connection between the 7-pin power supply unit connector and the 3-pin and 5-pin pin strip at the PC case:

Cable harness wiring diagram



 <b>Attention</b>	<p><b>Insert fuse</b></p> <p>The power supply of the customized components for shutting down the PC must be protected with a fuse! To this end, a "flying" fuse (6.3A/ medium time-lag) is inserted in the line.</p>
---	--

Note cable cross sections      The cable cross sections are 0.75 mm<sup>2</sup> / AWG18 for connecting the switch and 2.5 mm<sup>2</sup> / AWG14 (screened) for connecting the power supply.

### External wiring

The external wiring consists of the connection of the power supply, the battery pack (only C9900-P209) and the connection of customized components for shutting down the PC.

The external wiring occurs according to the wiring diagram, see chapter [Wiring diagram](#).

### Cable Cross Sections

Note cable cross sections, avoid voltage drop!      For the connection of the power supply, wiring with a cable-cross-section of 1.5 mm<sup>2</sup> must be used.


With bigger distances between voltage source and PC, you take the voltage drop as a function of the cable-cross-section as well as voltage fluctuations of your distribution voltage into account, so that is secured that the voltage doesn't fall under 22 V at the power supply.

 <b>Attention</b>	<p><b>Insert fuse</b></p> <p>The power supply must be protected with 16 A.</p>
---	--

### Power supply of the Industrial PC

The 5-pin pin strip with CAGE CLAMP connection and mounting flanges shown on the photograph is mounted on the PC case for connecting the power supply and the battery pack.

Pin assignment for connecting the power supply and the battery pack



Pin	Function
1	+ 24 V DC Power Supply
2	-
3	⊕
4	+ Battery Pack
5	- (C9900-P209 only)

### Configuration for shutting down the PC

The connections for shutting down the Industrial PCs are established via the **PC\_ON** input and the **Power Status** output. The third contact is connected to 24 V. To this end, a 3-pin pin strip with CAGE CLAMP connection and mounting flanges is installed at the PC case.

Pin assignment for connecting the on/off switch



Pin	Function
1	Power-Status
2	PC_ON
3	+ 24 V

### PC\_ON and Power Status functions

- If the **PC\_ON** input is connected to 24 V via a switch, the PC shuts down according to the rules. The **PC\_ON** signal is inverted, i.e. the PC shuts down if the 24 V connection is live.
- If the **PC\_ON** input is *NOT* connected by the user, the PC can be booted in the familiar way by connecting the supply voltage and shut down via the battery by switching off the supply voltage.

 <b>Attention</b>	<b>Service life of the rechargeable battery</b> This procedure significantly reduces the service life of the rechargeable battery and should therefore not be used.
---	--

- Once the PC has shut down, the **Power Status** output is switched from 24 V to 0 V. Via this output a signal lamp can be connected or a contactor for de-energizing the whole system. The maximum load for the **Power Status** output is 0.5 A and a suitable fuse should be provided.

### UPS output, C9900-P209 only

In order to maintain a screen display for the PC in the event of a power failure, the C9900-P209 power supply unit is equipped with a **UPS output** for connecting a Control Panel. The maximum load for the output is 1.4 A.


The UPS output is located on the power supply unit adjacent to the mains plug (see also section [Product Description](#)).

### UPS output function

- The 27 V DC connection at the UPS output is live even after a power failure. The maximum load is 1.4 A (C9900-P209 only).
- Once the PC has been de-energized via the UPS software, the **UPS output** is switched to 0 V. Any connected panel is thus switched off, and total discharge of the rechargeable battery is prevented.

# Wiring diagram

Wiring according to the wiring diagram.  
The circuit of PC\_ON and Power-Status is symbolical.



 <b>Note</b>	<p><b>Connection of the Battery Pack and UPS Output</b></p> <p>Connection of the Battery Pack and UPS Output only in combination with C9900-P209 power supply.</p>
--	--

## Installation of the supply cables

Wiring according to the wiring diagram


Install the cables for the power supply of the Industrial PC, the connection of the battery pack and the connection of the illuminated toggle switch according to the wiring diagram using the connector assembly material provided.

Connector assembly is described using the example of the 5-pole female plug connector:

Materials for assembly of the connector



Female plug connector, 5-pole



Strain relief housing

### Connector installation

Fitting the connector to the cable

The plug is fitted to the cable as follows:

1. Remove the insulation from the cable ends (8 - 9 mm).
2. Push the cable into the holders, applying slight pressure according to the pin assignment label and the wiring diagram.
3. Push the lower part (part **A**) of the strain relief housing onto the top of the female plug connector until it snaps into place.
4. Relieve the strain on the supply cable by fixing it in place with the cable clamp (part **C**) and fixing screws (part **D**) (see photograph below).

Applying the strain relief



Fix the upper part (part **B**) of the strain relief housing by snapping it onto the lower part.

# Operating Instructions

## UPS Software Components (only C9900-P209)

Installing the UPS driver software

For operating the power supply unit as a UPS, the UPS driver software and the associated UPS driver must be installed on the Industrial PC.

On delivery of the Beckhoff Industrial PC with operating system the software is already installed. Should the software not be installed on your PC, the drivers can be installed from the driver CD provided.

Installation

### Installation on the PC

To install the UPS driver software, execute file **Beckhoff\_UPS\_vx.xx.xx.exe** from the subdirectory of **UPS\...** from the CD provided on the Industrial PC (Driver-archive for the Industrial-PC, C9900-S700-xxxx).

The program is self-extracting and will guide the user through the installation routine.

Beckhoff Information System

### Help files

The driver software comes with a detailed help function. The help files can be called up either directly from the configuration register by clicking the Help button, or under via *Start > Programs > Beckhoff > UPS software components*.

## Servicing

The power supply unit is maintenance-free.

## Shutting down

Dismantling the case

### Disposal



The device must be fully dismantled in order to dispose of it. The housing can be sent for metal recycling.

Observe national electronics scrap regulations


Electronic parts must be disposed of in accordance with national electronics scrap regulations.

# Assembly dimensions

Device dimensions and mounting points.  
Dimensional notation in mm.




bottom view




front view



left view



rear view



top view

# Troubleshooting

In the event of a fault contact your **Beckhoff Service**.

## Beckhoff Support & Service

Beckhoff and their partners around the world offer comprehensive support and service, guaranteeing fast and competent assistance with all questions related to Beckhoff products and system solutions.

### Beckhoff branches and partner companies

Please contact your Beckhoff branch office or partner company for [local support and service](#) on Beckhoff products!

The contact addresses for your country can be found in the list of Beckhoff branches and partner companies: [www.beckhoff.com](http://www.beckhoff.com)

You will also find further [documentation](#) for Beckhoff components there.

### Beckhoff Headquarters

Beckhoff Automation GmbH  
Eiserstraße 5  
33415 Verl  
Germany

Phone: +49(0)5246/963-0  
Fax: +49(0)5246/963-198  
e-mail: [info@beckhoff.com](mailto:info@beckhoff.com)

### Beckhoff Support

Beckhoff offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with wide-ranging services:

- worldwide support
- design, programming and commissioning of complex automation systems
- training program for Beckhoff system components

Hotline: +49(0)5246/963-157  
Fax: +49(0)5246/963-9157  
e-mail: [support@beckhoff.com](mailto:support@beckhoff.com)

### Beckhoff Service

The Beckhoff service center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49(0)5246/963-460  
Fax: +49(0)5246/963-479  
e-mail: [service@beckhoff.com](mailto:service@beckhoff.com)

Quote the project number If servicing is required, please quote the **project number** of your product.

# Appendix

## Technical data

Electrical data	<b>Input voltage:</b> 22-30V DC/ 15A <b>Power output:</b> 250W (max.) <b>Output voltages:</b> see section <a href="#">Electrical data</a>				
Dimensions	<b>Dimensions (W x H x D):</b> 97.0 x 44.0 x 204.9 mm <b>Weight:</b> 0.85 kg				
Do not use the power supply unit in areas of explosive hazard	<b>The power supply unit must not be used where there is a risk of explosion.</b>				
Environmental conditions	<b>The following conditions must be observed during operation:</b> <b>Ambient temperature:</b> 0 to 55°C <b>Atmospheric humidity:</b> Maximum 95%, non-condensing				
Shock resistance	<b>Sinusoidal vibration (EN 60068-2-6):</b> <table> <tr> <td>10 to 58 Hz:</td> <td>0.035 mm</td> </tr> <tr> <td>58 to 500 Hz:</td> <td>0.5 G (~ 5 m/ s<sup>2</sup>)</td> </tr> </table> <b>Impact (EN 60068-2-27/ -29):</b> 5 G (~ 50 m/ s <sup>2</sup> ), duration: 30 ms	10 to 58 Hz:	0.035 mm	58 to 500 Hz:	0.5 G (~ 5 m/ s <sup>2</sup> )
10 to 58 Hz:	0.035 mm				
58 to 500 Hz:	0.5 G (~ 5 m/ s <sup>2</sup> )				
EMC compatibility	<b>Resistance to interference:</b> according to EN 61000-6-2 <b>Emission of interference:</b> according to EN 61000-6-4				
Transport and storage	The same values for atmospheric humidity and shock resistance are to be observed during transport and storage as in operation. The shock resistance during transport can be improved by appropriate packaging of the power supply unit. The ambient temperature during storage and transport must be between -20°C and +65°C.				

## Approvals

### FCC: Federal Communications Commission Radio Frequency Interference Statement

FCC Approval for USA

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### FCC: Canadian Notice

FCC Approval for Canada

This equipment does not exceed the Class A limits for radiated emissions as described in the Radio Interference Regulations of the Canadian Department of Communications.