


WORKSHOP MANUAL

PNEUMATIC PUMPS



INTENDED CONDITIONS OF USE

- ▶ To ensure that usage stipulations are met, read through the Operating Instructions completely before using the pump and observe all stipulations.
- ▶ Any departure from the usage stipulations (other fluid media, use of force) or user modifications (changes, use of non-original parts) can be dangerous and are considered as non-intended usage.
- ▶ The user is liable for any damage resulting from non-intended use. Before performing any repair and maintenance work, release the pressure in the system.
- ▶ Have repair and maintenance work only performed by qualified and skilled personnel.
- ▶ Only use genuine spare parts for repairs because otherwise the warranty will expire.

REPAIR/SERVICE

- ▶ The pumps were developed and produced according to the highest quality standards.
- ▶ Should a problem develop, despite all quality controls, please contact our customer service:

PRESSOL Schmiergeräte GmbH

Phone: +49 09462 17-216

Telefax: +49 09462 1063

service@pressol.com

- ▶ **The Workshop Manuals are available for download under www.pressol.com under the heading „Catalogues and brochures“.**
- ▶ For problem solving, Pressol provides detailed video clips which can be accessed under www.pressol.com/clips

WORKSHOP MANUAL

PNEUMATIC PUMPS

CONTENT

Page

Pneumatic Oil and Diesel Pump 1:1	5
Malfunctions - Causes - Solutions	6
Spare parts list/repair kits	10
<hr/>	
Pneumatic Radiator Antifreeze Pump 1:1	11
Malfunctions - Causes - Solutions	12
Spare parts list/repair kits	16
<hr/>	
Pneumatic Oil Pump 3:1	17
Malfunctions - Causes - Solutions	18
Spare parts list/repair kits	22
<hr/>	
Pneumatic oil pump 5:1	23
Malfunctions - Causes - Solutions	24
Spare parts list/repair kits	29
<hr/>	
Pneumatic grease pump 10:1	31
Malfunctions - Causes - Solutions	32
Spare parts list/repair kits	37
<hr/>	
Pneumatic grease pump 15:1	39
Malfunctions - Causes - Solutions	40
Spare parts list/repair kits	45
<hr/>	
Pneumatic grease pump 50:1	47
Malfunctions - Causes - Solutions	48
Spare parts list/repair kits	53
<hr/>	
Service, repair kits / parts lists	54

PNEUMATIC OIL AND DIESEL PUMP 1:1



PNEUMATIC OIL AND DIESEL PUMP 1:1

MALFUNCTIONS

Pump runs, but does not deliver sufficiently oil/diesel. Formation of foam.

Pump continues to run when the shut-off nozzle is closed (individual strokes at longer intervals)

CAUSES

Empty tank / container

Pump sucks in air

Defective / leaky suction valve in the pump cylinder

Leaky / defective valve in the pump piston

Leaky / defective sealing ring in the pump piston

SOLUTIONS

- ▶ Check and if required replace or refill container/tank **CLIP 7**
 - ▶ Check the complete suction line including connectors for tightness and if required reseal **CLIP 7**
 - ▶ Carefully heat up the screw joint of the pump cylinder [36] with a gas flame
 - ▶ Loosen the pump cylinder
 - ▶ Check the valve plate [34] for damage (bent) or dirt and check its seat in the pump cylinder [36] replace it if required
 - ▶ To do this, loosen the nut [33] **CLIP 1**
- required tools: **a/b/c/e/f**
- ▶ Carefully heat up the screw joint of the pump cylinder [36] with a gas flame
 - ▶ Loosen the pump cylinderr
 - ▶ Check the seat of the valve plate [29] on the piston pump [30] and check the valve spring [27] for damage or dirt and remplace them if required
 - ▶ To do this, remove the nut [31] and the pump piston [30] from the piston rod [12.4] **CLIP 1**
- required tools: **a/b/c/d**
- ▶ Check the sealing ring [32] for damage, dirt and wear and replace it if required **CLIP 1**
- required tools: **a/b/c/d**



- a** Fixture white
- b** Blow torch
- c** Open-end wrench WAF 46
- d** Open-end wrench WAF 14
- e** Open-end wrench WAF 8
- f** Socket wrench WAF 8



PNEUMATIC OIL AND DIESEL PUMP 1:1

MALFUNCTIONS

CAUSES

SOLUTIONS

Pump does not start or runs only for a short time

Excessive counterpressure

- ▶ Open the delivery valve, hose cross-section too small, hose too long **CLIP 8**

Pump works, but runs slowly or stops

Excessive viscosity of the medium

- ▶ maximum viscosity allowed up to SAE 15 W 5 at 15°C **CLIP 8**

Not enough compressed air

- ▶ Ensure sufficient supply of compressed air (max. air consumption 400 l/min)
- ▶ Dirty filter element [23]. For cleaning, remove the reducer, [24] with pressure reducing valve [25] and compressed air connector **CLIP 2**

required tools: **a / b**

Uninsufficient pressure

- ▶ Ensure sufficient supply of compressed air (recommended air pressure) 6 to 8 bar
- ▶ Defective pressure reducing valve [25]. Replace the valve **CLIP 2**

required tools: **a / b**

Dirty / icy silencer

- ▶ Clean the silencer, to do this, remove screws [1] and cage [2]
- ▶ Clean the silencer [3] with detergent and compressed air
- ▶ Use only lubricated compressed air (treatment unit with water separator and oil mister) **CLIP 2**

required tools: **c / d**



- a** Open-end wrench WAF 17
- b** Open-end wrench WAF 19
- c** Vice with soft jaws (not shown)
- d** Screwdriver, cross-recess



PNEUMATIK- OIL AND DIESEL PUMP 1:1

MALFUNCTIONS

Pump sputters
or stops

Pump stops, compressed air
continuously escapes through
the silencer

CAUSES

**Impurities in the
controller housing,
excessive wear of controller
parts, defective controller
parts**

SOLUTIONS

- ▶ Check the complete controller

Disassembly of the distributor:

- ▶ Loosen the screws [1] by a maximum of 2 turns
- ▶ Briefly apply compressed air to the pump to loosen the distributor
- ▶ Remove the screws [1] the cage [2] and the silencer [3] and take the complete distributor [4.1]
- ▶ Check the complete distributor assembly [4.1 – 4.6] especially the O-rings [4.2, 4.3, 4.4], the face of the distributor [4.1] the valve plate [4.5] and the clamp [4.6]
- ▶ In case of a defect, replace the complete assembly
- ▶ During assembly, pay attention to the correct position and the correct seat of the valve plate [4.5] and the clamp [4.6]

Disassembly of the shift levers:

- ▶ Loosen the screws [1.1] and remove the inserts [5] on both sides
- ▶ Remove the compression springs [6.2], sleeves [6.3] and shift levers [6.4] of the controller housing [18]
- ▶ Check the components for completeness (spalling, spring fracture)
- ▶ In case of a defect, replace always the complete components on both sides.
- ▶ Before assembly, put at first the O-rings [6.1] into the controller housing [18] then position the control valve [12.3] in central position on the piston rod and put the shift levers [6.3] and compression spring [6.2] pre-assembled with sleeve [6.4] into the two grooves at the control valve [12.3]
- ▶ Use the mounting aid (86896) to put the inserts [5] into the controller housing [18] and screw them down **CLIP 3**

required tools: **a/b/c/d**



- a** Vice with soft jaws (not shown)
- b** Screwdriver, cross-recess
- c** Lockable compressed air connection
- d** Needle-nose pliers



PNEUMATIK- OIL AND DIESEL PUMP 1:1

MALFUNCTIONS

CAUSES

SOLUTIONS

Pump stops, compressed air continuously escapes through the silencer

Leaky piston unit, leaky O-ring in the controller housing

- ▶ To do this, dismantle the complete control unit as described under 8.
- ▶ Dismantle the pump cylinder [36] and the piston [30], as described under 6
- ▶ Remove the screws [19]
- ▶ At the piston rod's [12.4] wrench flat, the pump body can then be fixed in a vice (with clamping jaws with smooth surfaces)
- ▶ Now, take off the pressure cylinder [7] loosen the nut [9] and remove the washer [10], the piston unit [11] and the levelling washer [13] from the piston rod [12.2]
- ▶ Check the piston unit [11] for damage (voids, cracks) and wear
- ▶ In addition, check and if required replace the O-ring [12.1] on the piston rod [12.2]
- ▶ Remove the screws [14] and the washer [15] to check the O-ring [16] **CLIP 4**

required tools: **a/b/c/d/e/f/g/h/i**

Oil escapes at the silencer

Condensed water/oil in the compressed air hose

- ▶ Empty the treatment unit, condensate separator, correctly adjust the oil mister **CLIP 6**

Defective seal between pump and controller

- ▶ To do this, dismantle the complete, control unit as described under 8
- ▶ Dismantle the pump cylinder [36] and the piston [30], as described under 6
- ▶ Remove the screws [19]
- ▶ Then, remove the connecting flange [21] from the controller housing [18] while holding the piston rod [12.4]
- ▶ Now, dismantle the adapter [22.4] and check the O-rings [22.1, 22.2, 22.3] and the sealing ring [22.5] for damage and wear
- ▶ If required, replace the complete adapter unit **CLIP 5**

required tools: **a/b/c/d/e/f/g/h/i/j**



- a** Vice with soft jaws (not shown)
- b** Blow torch
- c** Open-end wrench WAF 46
- d** Open-end wrench WAF 17
- e** Open-end wrench WAF 14
- f** Screwdriver, cross-recess
- g** Lockable compressed air connection
- h** Needle-nose pliers
- i** Allen key WAF 5
- j** Socket wrench WAF 24



PNEUMATIC OIL AND DIESEL PUMP 1:1

SPARE PARTS LIST

1	Gefu self-tapping screw M 5x16	87220
2	Cage	87207
3	Silencer	87227
4.1	Distributor	87204
4.2	O-ring-NBR 70-26 x 2	87223
4.3	O-ring-NBR 70-24 x 2	87224
4.4	O-ring-NBR 70-22 x 2	87225
4.5	Valve plate	87213
4.6	Clamp	87214
5	Insert	87206
6.1	O-ring NBR 70-26 x 2	87223
6.2	Compression spring	87215
6.3	Sleeve	87209
6.4	Shift lever	87210
7	Pressure cylinder	03268
8	O-ring NBR 70-81 x 1,5	03316
9	Nut DIN 985 M10	03311
10	Washer	87116
11	Piston unit NBR 70-80 x 22,5	03324
12.1	O-ring NBR 70-8 x 1	03262
12.2	Piston rod	87354
13	Levelling washer	03250
14	Gefu self-tapping screw M4 x 12	87221
15	Washer	87212
16	O-ring NBR 90-12 x 2	02380
17	O-ring NBR 70-8 x 1	03262
18	Controller housing	87211
19	Cylinder screw M 5x80	87222
20	O-ring NBR 70-35 x 1,5	87226
21	Connecting flange	87218
22.1	O-ring NBR 90-12 x 2	02380
22.2	O-ring NBR 70-14 x 1,78	88164
22.3	O-ring NBR 70-19 x 1,5	88165
22.4	Adapter	88152
22.5	Lip seal NBR 72-20 x 12 x 5,5	03338
22.6	Locking ring DIN 984-20 x 1	03264
23	Filter element	87228
24	Reducer	20122
25	Pressure reducing valve	04698
26	Washer, curved	03509
27	Compression spring	02851
28	Washer	03507
29	Valve plate	03410
30	Pump piston	02847

31	Nut	03415
32	Lip seal NBR 84 80 x 68 x 8,5mm	03389
33	Nut	01085
34	Valve plate	03417
35	O-ring NBR 70-82 x 2,5	02850
36	Pump cylinder	02855
37	Valve rod	03336
38	Compression spring	02852
39	Washer	02853

REPAIR KITS

Seal kit	72070
Piston rod	87354
Shift lever	72090
Distributor	87351

PNEUMATIC RADIATOR ANTIFREEZE PUMP 1:1



PNEUMATIC RADIATOR ANTIFREEZE PUMP 1:1

MALFUNCTIONS	CAUSES	SOLUTIONS
Pump runs, but does not deliver (sufficiently) oil/diesel, formation of foam	Empty tank / container	<ul style="list-style-type: none">▶ Check and if required replace or refill container/tank CLIP 7
Pump continues to run when the shut-off nozzle is closed (individual strokes at longer intervals)	Pump sucks in air	<ul style="list-style-type: none">▶ Check the complete suction line including connectors for tightness and if required reseal CLIP 7
	Defective / leaky suction valve in the pump cylinder	<ul style="list-style-type: none">▶ Carefully heat up the screw joint of the pump cylinder [36] with a gas flame▶ Loosen the pump cylinder▶ Check the seat of the valve plate [34] on the piston pump [36] for damage or dirt and remplace them if required▶ To do this, loosen the nut [33] CLIP 1 <p>required tools: a/b/c/e/f</p>
	Leaky / defective valve in the pump piston	<ul style="list-style-type: none">▶ Carefully heat up the screw joint of the pump cylinder [36] with a gas flame▶ Loosen the pump cylinder▶ Check the seat of the valve plate [29] on the piston pump [30] and the valve spring [27] for damage or dirt and replace them if required▶ To do this, remove the nut [31] and the pump piston [30] from the piston rod [12.4] CLIP 1 <p>required tools: a/b/c/d</p>
	Leaky / defective sealing ring in the pump piston	<ul style="list-style-type: none">▶ Check the sealing ring [32] for damage, dirt and wear and replace it if required CLIP 1 <p>required tools: a/b/c/d</p>



- a** Fixture white
- b** Blow torch
- c** Open-end wrench WAF 46
- d** Open-end wrench WAF 14
- e** Open-end wrench WAF 8
- f** Socket wrench WAF 8



PNEUMATIC RADIATOR ANTIFREEZE PUMP 1:1

MALFUNCTIONS

CAUSES

SOLUTIONS

Pump does not start or runs only for a short time

Excessive counterpressure

- ▶ Open the delivery valve, hose cross-section too small, hose too long **CLIP 8**

Pump works, but runs slowly or stops

Excessive viscosity of the medium

- ▶ Maximum viscosity allowed up to SAE 15 W 5 at 15°C **CLIP 8**

Not enough compressed air

- ▶ Ensure sufficient supply of compressed air (max. air consumption 400 l/min)
- ▶ Dirty filter element [23]. For cleaning, remove the reducer [24] with pressure reducing valve [25] and compressed air connector **CLIP 2**

required tools: **a / b**

Uninsufficient pressure

- ▶ Ensure sufficient supply of compressed air (recommended air pressure 6 to 8 bar)
- ▶ Defective pressure reducing valve [25]. Replace the valve **CLIP 2**

required tools: **a / b**

Dirty / icy silencer

- ▶ Clean the silencer. To do this, remove screws [1] and cage [2]
- ▶ Clean the silencer [3] with detergent and compressed air
- ▶ Use only lubricated compressed air (treatment unit with water separator and oil mister) **CLIP 2**

required tools: **c / d**



- a** Open-end wrench WAF 17
- b** Open-end wrench WAF 19
- c** Vice with soft jaws (not shown)
- d** Screwdriver, cross-recess



PNEUMATIC RADIATOR ANTIFREEZE PUMP 1:1

MALFUNCTIONS	CAUSES	SOLUTIONS
<p>Pump sputters or stops</p> <p>Pump stops. Compressed air continuously escapes through the silencer</p>	<p>Impurities in the controller housing, excessive wear of controller parts, defective controller parts</p>	<p>► Check the complete controller</p> <p>Disassembly of the distributor:</p> <p>► Loosen the screws [1] by a maximum of 2 turns</p> <p>► Briefly apply compressed air to the pump to loosen the distributor.</p> <p>► Remove the screws [1] the cage [2] and the silencer [3] and take off the complete distributor [4.1]</p> <p>► Check the complete distributor assembly [4.1 – 4.6], especially the O-rings [4.2, 4.3, 4.4], the face of the distributor [4.1] the valve plate [4.5] and the clamp [4.6]</p> <p>► In case of a defect, replace the complete assembly</p> <p>► During assembly, pay attention to the correct position and the correct seat of the valve plate [4.5] and the clamp [4.6]</p> <p>Disassembly of the shift levers:</p> <p>► Loosen the screws [1.1] and remove the inserts [5] on both sides</p> <p>► Remove the compression springs [6.2], sleeves [6.3] and shift levers [6.4] of the controller housing [18]</p> <p>► Check the components for completeness (spalling, spring fracture)</p> <p>► In case of a defect, replace always the complete components on both sides</p> <p>► Before assembly, put at first the O-rings [6.1] into the controller housing [18] then position the control valve [12.3] in central position on the piston rod and put the shift levers [6.4] pre-assembled with sleeve [6.3] and compression spring [6.2] into the two grooves at the control valve [12.3]</p> <p>► Use the mounting aid (86896) to put the inserts [5] into the controller housing [18] and screw them down CLIP 3</p> <p>required tools: a / b / c / d</p>



- a Vice with soft jaws (not shown)
- b Screwdriver, cross-recess
- c Lockable compressed air connection
- d Needle-nose pliers



PNEUMATIC RADIATOR ANTIFREEZE PUMP 1:1

MALFUNCTIONS

CAUSES

SOLUTIONS

Pump stops, compressed air continuously escapes through the silencer

Leaky piston unit, leaky O-ring in the controller housing

- ▶ To do this, dismantle the complete control unit as described under 14
- ▶ Dismantle the pump cylinder [36] and the piston [30], as described under 12
- ▶ Remove the screws [19]
- ▶ At the piston rod's [12.4] wrench flat, the pump body can then be fixed in a vice (with clamping jaws with smooth surfaces)
- ▶ Now, take off the pressure cylinder [7], loosen the nut [9] and remove the washer [10], the piston unit [11] and the levelling washer [13] from the piston rod [12.2]
- ▶ Check the piston unit [11] for damage (voids, cracks) and wear
- ▶ In addition, check and if required replace the O-ring [12.1] on the piston rod [12.2]
- ▶ Remove the screws [14] and the washer [15] to check the O-ring [16] **CLIP 4**

required tools: **a/b/c/d/e/f/g/h/i**

Oil escapes at the silencer

Condensed water/oil in the compressed air hose

- ▶ Empty the treatment unit / condensate separator, correctly adjust the oil mister. **CLIP 6**

Defective seal between pump and controllert

- ▶ To do this, dismantle the complete control unit as described under 14
- ▶ Dismantle the pump cylinder [36] and the piston [30], as described under 12
- ▶ Remove the screws [19]
- ▶ Then, remove the connecting flange [21] from the controller housing [18] while holding the piston rod [12.4]
- ▶ Now, dismantle the adapter [22.4] and check the O-rings [22.1, 22.2, 22.3] and the sealing ring [22.5] for damage and wear
- ▶ If required, replace the complete adapter unit **CLIP 5**

required tools: **a/b/c/d/e/f/g/h/i/j**



- a** Vice with soft jaws (not shown)
- b** Blow torch
- c** Open-end wrench WAF 46
- d** Open-end wrench WAF 17
- e** Open-end wrench WAF 14
- f** Screwdriver, cross-recess
- g** Lockable compressed air connection
- h** Needle-nose pliers
- i** Allen key WAF 5
- j** Socket wrench WAF 24



PNEUMATIC RADIATOR ANTIFREEZE PUMP 1:1

SPARE PARTS LIST

1	Gefu self-tapping screw M 5x16	87220
1.1	Gefu self-tapping screw M 5x16	87220
2	Cage	87207
3	Silencer	87227
4.1	Distributor	87204
4.2	O-ring NBR 70-26 x 2	87223
4.3	O-ring NBR 70-24 x 2	87224
4.4	O-ring NBR 70-22 x 2	87225
4.5	Valve plate	87213
4.6	Clamp	87214
5	Insert	87206
6.1	O-ring NBR 70-26 2	87223
6.2	Compression spring	87215
6.3	Sleeve	87209
6.4	Shift lever	87210
7	Pressure cylinder	03268
8	O-ring NBR 70-81 1,5	03316
9	Nut DIN 985 M10	03311
10	Washer	87116
11	Piston unit NBR 70-80 x 22,5	03324
12.1	O-ring NBR 70-8 x 1	03262
12.2	Piston rod	87354
13	Levelling washer	03250
14	Gefu self-tapping screw M4 x 12	87221
15	Washer	87212
16	O-ring NBR 90-12 x 2	02380
17	O-ring NBR 70-8 x 1	03262
18	Controller housing	87211
19	Cylinder screw M5 x 80	87222
20	O-ring NBR 70-35 x 1,5	87226
21	Connecting flange	87218
22.1	O-ring NBR 90-12 x 2	02380
22.2	O-ring NBR 70-14 x 1,78	88164
22.3	O-ring NBR 70-19 x 1,5	88165
22.4	Adapter	88152
22.5	Rod seal 12 x 20 x 5,5	87791
22.6	Locking ring DIN 984-20 x 1	03264
23	Filter element	87228
24	Reducer	20122
25	Pressure reducing valve	04698
26	Washer, curved	03509
27	Compression spring	02851
28	Washer	03507
29	Valve plate 60 x 10,6 mm	03410
30	Pump piston	02847

31	Nut	03415
32	Piston seal 80 x 68 x 8,5	87792
33	Nut	01085
34	Valve plate	03417
35	O-ring NBR 70-82 x 2,5	02850
36	Pump cylinder	87790
37	Valve rod	03336
38	Compression spring	02852
39	Washer	02853

REPAIR KITS

Piston rod	87354
Shift lever	72090
Distributor	87351

PNEUMATIC OIL PUMP 3:1



MALFUNCTIONS

CAUSES

SOLUTIONS

Pump runs, but does not deliver (sufficiently) oil, formation of foam

Empty tank / container

- ▶ Check and if required replace or refill container/tank **CLIP 7**

Pump continues to run when the shut-off nozzle is closed (individual strokes at longer intervals)

Pump sucks in air

- ▶ Check the complete suction line including connectors for tightness and if required reseal **CLIP 7**

Defective / leaky suction valve in the pump cylinder

- ▶ Carefully heat up the screw joint of the pump cylinder [36] with a gas flame
- ▶ Loosen the pump cylinder
- ▶ Check the valve plate [35] and its seat in the pump cylinder [36] for damage (bent) or dirt and replace it if required
- ▶ To do this, loosen the nut [34] **CLIP 9**

required tools: **a/b/c/e/f**

Leaky / defective valve in the pump piston

- ▶ Carefully heat up the screw joint of the pump cylinder [36] with a gas flame
- ▶ Loosen the pump cylinder
- ▶ Check the valve ball [29] its seat in the valve screw [31] and the valve spring [28] for damage or dirt and replace them if required
- ▶ Remove the clamping sleeve [26], unscrew the pump piston unit [27] from the piston rod [12.4] and loosen the valve screw [31]
- ▶ During assembly in reverse order – pay attention to the correct seat of the valve spring [28] under the clamping sleeve [26] **CLIP 9**

required tools: **a/b/c/d/g/h/ i**

Leaky / defective sealing ring in the pump piston

- ▶ Check the sealing ring [32] for damage, dirt and wear and replace it if required **CLIP 9**

required tools: **a/b/c/d/g/h/ i**



- a Fixture white
- b Blow torch
- c Open-end wrench WAF 36
- d Open-end wrench WAF 32
- e Open-end wrench WAF 8
- f Socket wrench WAF 8
- g Pin punch D3 and D5
- h Water pump pliers
- i Hammer



MALFUNCTIONS

CAUSES

SOLUTIONS

Pump does not start or runs only for a short time

Excessive counterpressure

- ▶ Open the delivery valve, hose cross-section too small, hose too long **CLIP 8**

Pump works, but runs slowly or stops

Excessive viscosity of the medium

- ▶ Maximum viscosity allowed up to SAE 90 at 15°C **CLIP 8**

Not enough compressed air

- ▶ Ensure sufficient supply of compressed air (max. air consumption 400l/min)
- ▶ Dirty filter element [23]. For cleaning, remove the reducer [24] with pressure reducing valve [25] and compressed air connector **CLIP 2**

required tools: **a / b**

Uninsufficient pressure

- ▶ Ensure sufficient supply of compressed air (recommended air pressure 6 to 8 bar)
- ▶ Defective pressure reducing valve [25]. Replace the valve **CLIP 2**

required tools: **a / b**

Dirty / icy silencer

- ▶ Clean the silencer. To do this, remove the screws [1] and cage [2]
- ▶ Clean the silencer [3] with detergent and compressed air
- ▶ Use only lubricated compressed air (treatment unit with water separator and oil mister) **CLIP 2**

required tools: **c / d**



- a** Open-end wrench WAF 17
- b** Open-end wrench WAF 19
- c** Vice with soft jaws (not shown)
- d** Screwdriver, cross-recess



MALFUNCTIONS	CAUSES	SOLUTIONS
Pump sputters or stops	Impurities in the controller housing, excessive wear of controller parts, defective controller parts	<ul style="list-style-type: none">▶ Check the complete controller
Pump stops		<p>Disassembly of the distributor:</p> <ul style="list-style-type: none">▶ Loosen the screws [1] by a maximum of 2 turns▶ Briefly apply compressed air to the pump to loosen the distributor▶ Remove the screws [1] the cage [2] and the silencer [3] and take off the complete distributor [4.1]▶ Check the complete distributor assembly [4.1 – 4.6], especially the O-rings [4.2, 4.3, 4.4], the face of the distributor [4.1] the valve plate [4.5], and the clamp [4.6]▶ In case of a defect, replace the complete assembly.▶ During assembly, pay attention to the correct position and the correct seat of the valve plate [4.5] and the clamp [4.6]
Compressed air continuously escapes through the silencer		<p>Disassembly of the shift levers:</p> <ul style="list-style-type: none">▶ Loosen the screws [1.1] and remove the inserts [5] on both sides▶ Remove the compression springs [6.2], sleeves [6.3] and shift levers [6.4] of the controller housing [18]▶ Check the components for completeness (spalling, spring fracture).▶ In case of a defect, replace always the complete components on both sides▶ Before assembly, put at first the O-rings [6.1] into the controller housing [18] then position the control valve [12.3] in central position on the piston rod and put the shift levers [6.4]; pre-assembled with sleeve [6.3] and compression spring [6.2], into the two grooves at the control valve [12.3]▶ Use the mounting aid (86896) to put the inserts [5] into the controller housing [18] and screw them down CLIP 3 <p>required tools: a/b/c/d</p>



- a Vice with soft jaws (not shown)
- b Screwdriver, cross-recess
- c Lockable compressed air connection
- d Needle-nose pliers



PNEUMATIC OIL PUMP 3:1

MALFUNCTIONS

CAUSES

SOLUTIONS

Pump stops compressed air continuously escapes through the silencer

Leaky piston unit, leaky O-ring in the controller housing

- ▶ To do this, dismantle the complete control unit as described under 20
- ▶ Dismantle the pump cylinder [36] and the piston [27], as described under 18
- ▶ Remove the screws [19]
- ▶ At the piston rod's [12.4] wrench flat, the pump body can then be fixed in a vice (with clamping jaws with smooth surfaces)
- ▶ Now, take off the pressure cylinder [7] loosen the nut [9] and remove the washer [10], the piston unit [11] and the levelling washer [13] from the piston rod [12.2]
- ▶ Check the piston unit [11] for damage (voids, cracks) and wear
- ▶ In addition, check and if required replace the O-ring [12.1] on the piston rod [12.2]
- ▶ Remove the screws [14] and the washer [15] to check the O-ring [16] **CLIP 4**

required tools: **a/b/c/d/e/f/g/h/i/j/k/l**

Oil escapes at the silencer

Condensed water/oil in the compressed air hose

- ▶ Empty the treatment unit / condensate separator, correctly adjust the oil mister. **CLIP 6**

Defective seal between pump and controller

- ▶ To do this, dismantle the complete control unit as described under 20.
- ▶ Dismantle the pump cylinder [36] and the piston [27], as described under 18
- ▶ Remove the screws [19]
- ▶ Then, remove the connecting flange[21] from the controller housing [18] while holding the piston rod [12.4]
- ▶ Now, dismantle the adapter [22.4] and check the O-rings [22.1, 22.2, 22.3] and the sealing ring [22.5] for damage and wear
- ▶ If required, replace the complete adapter unit **CLIP 5**

required tools: **a/b/c/d/e/f/g/h/i/j/k/l/m**



- a** Vice with soft jaws (not shown)
- b** Blow torch
- c** Open-end wrench WAF 36
- d** Open-end wrench WAF 32
- e** Open-end wrench WAF 17
- f** Pin punch D3 and D5
- g** Water pump pliers
- h** Hammer
- i** Screwdriver, cross-recess
- j** Lockable compressed air connection
- k** Needle-nose pliers
- l** Allen key WAF 5
- m** Socket wrench WAF 24



SPARE PARTS LIST

1	Gefu self-tapping screw M 5x16	87220
1.1	Gefu self-tapping screw M 5x16	87220
2	Cage	87207
3	Silencer	87227
4.1	Distributor	87204
4.2	O-ring NBR 70-26 x 2	87223
4.3	O-ring NBR 70-24 x 2	87224
4.4	O-ring NBR 70-22 x 2	87225
4.5	Valve plate	87213
4.6	Clamp	87214
5	Insert	87206
6.1	O-ring-NBR 70-26 x 2	87223
6.2	Compression spring	87215
6.3	Sleeve	87209
6.4	Shift lever	87210
7	Pressure cylinder	03268
8	O-ring NBR 70-81 x 1,5	03316
9	Nut DIN 985 M10	03311
10	Washer	87116
11	Piston unit NBR 70-80 x 22,5	03324
12.1	O-ring NBR 70-8 x 1	03262
12.2	Piston rod	87353
13	Levelling washer	03250
14	Gefu self-tapping screw M4 x 12	87221
15	Washer	87212
16	O-ring NBR 90-12 x 2	02380
17	O-ring NBR 70-8 x 1	03262
18	Controller housing	87211
19	Cylinder screw M5 x 80	87222
20	O-ring NBR 70-35 x 1,5	87226
21	Connecting flange	87217
22.1	O-ring NBR 90-12 x 2	02380
22.2	O-ring NBR 70-14 x 1,78	88164
22.3	O-ring NBR 70-19 x 1,5	88165
22.4	Adapter	88152
22.5	Lip seal PU 93 20 x 12 x 5,7 mm	03387
22.6	Locking ring DIN 984-20 x 1	03264
23	Filter element	87228
24	Reducer	20122
25	Pressure reducing valve	04698
26	Slotted spring pin DIN 1481	87630
27	Pump piston	02844
28	Compression spring	02851
29	Steel ball, D= 17 mm	03263
30	O-ring 26.7 x 1.78 PU 90	87521

31	Screw WAF 32	87646
32	Lip seal NBR 84-48 x 40x5,5	03390
33	O-ring NBR 70-53 x 2	02849
34	Nut DIN 985	01085
35	Valve plate	03416
36	Pump cylinder	02854
37	Valve rod	03336
38	Compression spring	02852
39	Unterlegscheibe	02853

REPAIR KITS

Seal kit	72071
Piston rod	87353
Shift lever	72090
Distributor	87351

PNEUMATIC OIL PUMP 5:1



MALFUNCTIONS

CAUSES

SOLUTIONS

Pump runs, but does not deliver (sufficiently) oil/diesel. Formation of foam

Empty tank / container
Pump sucks in air

- ▶ Check and if required replace or refill container/tank **CLIP 7**
- ▶ Check the complete suction line including connectors for tightness and if required reseal **CLIP 7**

Pump continues to run when the shut-off nozzle is closed (individual strokes at longer intervals)

Defective / leaky suction valve in the pump cylinder

- ▶ Carefully heat up the screw joint of the pump cylinder [40] with a gas flame
- ▶ Loosen the pump cylinder
- ▶ Check the valve ball [39] and its seat in the pump cylinder [40] or damage or dirt and replace then if required
- ▶ To do this, loosen the locking ring [36] and remove the pin [37] **CLIP 10**

required tools: **a/b/c/e/f**

Leaky / defective valve in the pump piston

- ▶ Carefully heat up the screw joint of the pump cylinder [40] with a gas flame
- ▶ Loosen the pump cylinder
- ▶ Check the valve ball [32] its seat in the valve screw [34], and the valve spring [31] for damage or dirt and replace them if required
- ▶ To do this, remove the pump piston unit [29] and proceed as follows:
Remove the clamping sleeve [30], unscrew the pump piston unit [29] from the piston rod [12.4] and loosen the valve screw [34]. During assembly in reverse order pay attention to the correct seat of the valve spring [31] under the clamping sleeve [30] **CLIP 10**

required tools: **a/b/c/d/g/h/i**

Leaky / defective sealing ring in the pump piston

- ▶ Check the sealing ring [35] for damage, dirt and wear and replace it if required **CLIP 10**

required tools: **a/b/c/d/g/h/i**



- a Fixture white
- b Blow torch
- c Open-end wrench WAF 36
- d Open-end wrench WAF 32
- e Locking ring pliers, internal
- f Needle-nose pliers
- g Pin punch D3 and D5
- h Water pump pliers
- i Hammer



MALFUNCTIONS

CAUSES

SOLUTIONS

Pump does not start or runs only for a short time

Excessive counterpressure

- ▶ Open the delivery valve, hose cross-section too small, hose too long **CLIP 8**

Pump works, but pump runs slowly or stops

Excessive viscosity of the medium

- ▶ maximum viscosity allowed up to SAE 140 at 15°C **CLIP 8**

Not enough compressed air

- ▶ Ensure sufficient supply of compressed air (max. air consumption 400l/min)
- ▶ Dirty filter element [23]. For cleaning, remove the reducer [24] with pressure reducing valve [25] and compressed air connector **CLIP 2**

required tools: **a / b**

Uninsufficient pressure

- ▶ Ensure sufficient supply of compressed air (recommended air pressure 6 to 8 bar)
- ▶ Defective pressure reducing valve [25]. Replace the valve **CLIP 2**

required tools: **a / b**

Dirty / icy silencer

- ▶ Clean the silencer. To do this, remove screws [1] und cage [2]
- ▶ Clean the silencer [3] with detergent and compressed air
- ▶ Use only lubricated compressed air (treatment unit with water separator and oil mister) **CLIP 2**

required tools: **c / d**



- a** Open-end wrench WAF 19
- b** Open-end wrench WAF 17
- c** Vice with soft jaws (not shown)
- d** Screwdriver, cross-recess



MALFUNCTIONS	CAUSES	SOLUTIONS
<p>Pump sputters or stops</p> <p>Pump stops, compressed air continuously escapes through the silencer</p>	<p>Impurities in the controller housing, excessive wear of controller parts, defective controller parts</p>	<p>► Check the complete controller</p> <p>Disassembly of the distributor:</p> <p>► Loosen the screws [1] by a maximum of 2 turns</p> <p>► Briefly apply compressed air to the pump to loosen the distributor</p> <p>► Remove the screws [1] the cage [2] and the silencer [3] and take off the complete distributor [4.1]</p> <p>► Check the complete distributor assembly [4.1 – 4.6] especially the O-rings [4.2, 4.3, 4.4], the face of the distributor [4.1] the valve plate [4.5] sand the clamp [4.6]</p> <p>► In case of a defect, replace the complete assembly.</p> <p>► During assembly, pay attention to the correct position and the correct seat of the valve plate [4.5] and the clamp [4.6]</p> <p>Disassembly of the shift levers:</p> <p>► Loosen the screws [1.1] and remove the inserts [5] on both sides</p> <p>► Remove the compression springs [6.2], sleeves [6.3] and shift levers [6.4] of the controller housing [18]</p> <p>► Check the components for completeness (spalling, spring fracture)</p> <p>► In case of a defect, replace always the complete components on both sides</p> <p>► Before assembly, put at first the O-rings [6.1] into the controller housing [18], then position the control valve [12.3] in central position on the piston rod and put the shift levers [6.4] pre-assembled with sleeve [6.3] and compression spring [6.2] into the two grooves at the control valve [12.3]</p> <p>► Use the mounting aid(86896) to put the inserts [5] into the controller housing [18] and screw them down CLIP 3</p> <p>required tools: a/b/c/d</p>



- a Vice with soft jaws (not shown)
- b Screwdriver, cross-recess
- c Lockable compressed air connection
- d Needle-nose pliers



PNEUMATIC OIL PUMP 5:1

MALFUNCTIONS

CAUSES

SOLUTIONS

Pump stops, compressed air continuously escapes through the silencer

Leaky piston unit, leaky O-ring in the controller housing

- ▶ Dismantle the complete controller as described under 26
- ▶ Dismantle the pump cylinder [40] and the piston [29], as described under 24
- ▶ Remove the screws [19]
- ▶ At the piston rod's [12.4] wrench flat, the pump body can then be fixed in a vice (with clamping jaws with smooth surfaces)
- ▶ Now, take off the pressure cylinder [7] loosen the nut [9] and remove the washer [10], the piston unit [11] and the levelling washer [13] from the piston rod [12.2]
- ▶ Check the piston unit [11] for damage (voids, cracks) and wear
- ▶ In addition, check and if required replace the O-ring [12.1] on the piston rod [12.2]
- ▶ To check the O-ring [16] remove the screws [14] and the washer [15] **CLIP 4**

required tools: **a/b/c/d/e/f/g/h/i/j/k/l**

Oil escapes at the silencer

Condensed water/oil in the compressed air hose

- ▶ Empty the treatment unit / condensate separator, correctly adjust the oil mister **CLIP 6**

Defective seal between pump and controller

- ▶ To do this, dismantle the complete controller as described under 26
- ▶ Dismantle the pump cylinder [40] and the piston [29], as described under 24
- ▶ Remove the screws [19]
- ▶ Then, remove the connecting flange [21] from the controller housing [18] while holding the piston rod [12.4]
- ▶ Now, dismantle the adapter [22.4] and check the O-rings [22.1, 22.2, 22.3] and the sealing ring [22.5] for damage and wear
- ▶ If required, replace the complete adapter unit **CLIP 5**

required tools: **a/b/c/d/e/f/g/h/i/j/k/l/m**



- a** Vice with soft jaws (not shown)
- b** Blow torch
- c** Open-end wrench WAF 36
- d** Open-end wrench WAF 32
- e** Open-end wrench WAF 17
- f** Pin punch D3 and D5
- g** Water pump pliers
- h** Hammer
- i** Screwdriver, cross-recess
- j** Lockable compressed air connection
- k** Needle-nose pliers
- l** Allen key WAF 5
- m** Socket wrench WAF 24



b



c



d



e



f



g



h



i



j



k



l



m

PNEUMATIC OIL PUMP 5:1

MALFUNCTIONS

Oil escapes between connecting flange and controller housing

CAUSES

Defective O-ring in the connecting flange

SOLUTIONS

- ▶ To do this, dismantle the complete control unit as described under 26
- ▶ Dismantle the pump cylinder [40] and the piston [29], as described under 24
- ▶ Remove the screws [19]
- ▶ Then, remove the connecting flange [21] from the controller housing [18] while holding the piston rod [12.4]
- ▶ Now, dismantle the locking ring [28] and the sealing ring [27] and check them for damage and wear **CLIP 11**

required tools: **a/b/c/d/e/f/g/h/i/j/k/l/m**



- a Vice with soft jaws (not shown)
- b Blow torch
- c Open-end wrench WAF 36
- d Open-end wrench WAF 32
- e Open-end wrench WAF 17
- f Socket wrench WAF 24
- g Allen key WAF 5
- h Lockable compressed air connection
- i Pin punch D3 and D5
- j Water pump pliers
- k Hammer
- l Screwdriver, cross-recess
- m Needle-nose pliers



b



c



d



e



f



g



h



i



j



k



l



m

PNEUMATIC OIL PUMP 5:1

SPARE PARTS LIST

1	Gefu self-tapping screw M 5x16	87220
1.1	Gefu self-tapping screw M 5x16	87220
2	Cage	87207
3	Silencer	87227
4.1	Distributor	87204
4.2	O-ring NBR 70-26 x 2	87223
4.3	O-ring NBR 70-24 x 2	87224
4.4	O-ring NBR 70-22 x 2	87225
4.5	Valve plate	87213
4.6	Clamp	87214
5	Insert	87206
6.1	O-ring NBR 70-26 x 2	87223
6.2	Compression spring	87215
6.3	Sleeve	87209
6.4	Shift lever	87210
7	Pressure cylinder	03268
8	O-ring NBR 70-81 x 1,5	03316
9	Nut DIN 985 M10	03311
10	Washer	87116
11	Piston unit NBR 70-80 x 22,5	03324
12.1	O-ring NBR 70-8 x 1	03262
12.2	Piston rod	87655
13	Levelling washer	03250
14	Gefu self-tapping screw M4 x 12	87221
15	Washer	87212
16	O-ring NBR 90-12 x 2	02380
17	O-ring NBR 70-8 x 1	03262
18	Controller housing	87211
19	Cylinder screw M5 x 80	87222
20	O-ring NBR 70-35 x 1,5	87226
21	Connecting flange 5:1	87642
22.1	O-ring NBR 90-12 x 2	02380
22.2	O-ring NBR 70-14 x 1,78	88164
22.3	O-ring NBR 70-19 x 1,5	88165
22.4	Adapter	88152
22.5	Lip seal PU 93 20 x 12 x 5,7 mm	03387
22.6	Locking ring DIN 984-20 x 1	03264
23	Filter element	87228
24	Reducer	20122
25	Pressure reducing valve	04698
26	Support washer	87648
27	Lip seal NBR 90 44 x 34 x 7 mm	87632
28	Locking ring	87634
29.1	Piston tube	88168
29.2	Stop plate	88113
29.3	Lip seal PU 93 20 x 12 x 5,7 mm	03387
29.4	O-ring 26.7x1.78 PU 90	87521
29.5	Double piston	87645

30	Slotted spring pin DIN 1481	87630
31	Compression spring	02851
32	Steel ball, D = 17 mm	03263
33	O-ring 26.7x1.78 PU 90	87521
34	Screw	87646
35	Lip seal NBR 84-48 x 40 x 5,5	03390
36	Locking ring	03328
37	Locking pin	87746
38	O-ring NBR 70	87629
39	Steel ball, D = 19,05 mm	87631
40	Pump cylinder	87643

REPAIR KITS

Seal kit	72072
Piston rod	87655
Shift lever	72090
Distributor	87351

PNEUMATIC GREASE PUMP 10:1



PNEUMATIC GREASE PUMP 10:1

MALFUNCTIONS	CAUSES	SOLUTIONS
Pump runs, but does not deliver sufficiently grease	Empty tank / container	<ul style="list-style-type: none">▶ Check and if required replace container CLIP 12
Pump continues to run when the shut-off nozzle is closed (individual strokes at longer intervals)	Pump sucks in air	<ul style="list-style-type: none">▶ Run the pump at a maximum pressure of 3 bar and loosen the pressure hose directly at the pump for venting▶ Press the follower plate down in the container until grease escapes from the center boring▶ Shake the container CLIP 12
	Defective / leaky suction valve in the pump cylinder	<ul style="list-style-type: none">▶ Check the suction valve [37] for damage or dirt and replace it if required▶ To do this, unscrew the complete valve [37] out of the pump cylinder [35] and dismantle the clamping sleeve [38].▶ Check the interior sealing surface in the suction valve [37] and the valve cone [36] and replace them if damaged CLIP 16 <p>required tools: a / b / c / d</p>
	Leaky / defective valve in the pump piston	<ul style="list-style-type: none">▶ Check the valve, to do this, remove the complete suction valve [37] and the pump cylinder [35]▶ Screw the valve screw [34] out of the piston [29] while holding the piston▶ Clean and check the valve ball [33] and the ball seat in the valve screw [34] and replace it if required CLIP 16 <p>required tools: a / e / f / g</p>
	Leaky / defective sealing ring in the pump piston	<ul style="list-style-type: none">▶ Check the sealing ring, to do this, remove the complete suction valve [37] and the pump cylinder [35]▶ Clean and check the sealing ring [30] if damaged, replace also the O-ring below it CLIP 16 <p>required tools: a / e / f / g</p>



- a Vice with soft jaws (not shown)
- b Water pump pliers
- c Pin punch D3 and D5
- d Hammer
- e 2x Pipe wrench
- f Open-end wrench WAF 14
- g Allen key WAF 8



MALFUNCTIONS

CAUSES

SOLUTIONS

Pump does not start or runs only for a short time

Excessive counterpressure

- ▶ Open the delivery valve, hose cross-section too small, hose too long **CLIP 8**

Pump works, but pump runs slowly or stops

Excessive viscosity of the medium

- ▶ Maximum admissible degree of consistency NLGI 3 at 15°C **CLIP 8**

Not enough compressed air

- ▶ Ensure sufficient supply of compressed air (max. air consumption 400 l/min)
- ▶ Dirty filter element [23]. For cleaning, remove the reducer [24] with pressure reducing valve [25] and compressed air connector **CLIP 2**

required tools: **a / b**

Uninsufficient pressure

- ▶ Ensure sufficient supply of compressed air (recommended air pressure 6 to 8 bar)
- ▶ Defective pressure reducing valve [25]. Replace the valve **CLIP 2**

required tools: **a / b**

Dirty / icy silencer

- ▶ Clean the silencer, To do this, remove screws [1] and cage [2]
- ▶ Clean the silencer [3] with detergent and compressed air
- ▶ Use only lubricated compressed air (treatment unit with water separator and oil mister) **CLIP 2**

required tools: **c / d**



- a** Open-end wrench WAF 19
- b** Open-end wrench WAF 17
- c** Vice with soft jaws (not shown)
- d** Screwdriver, cross-recess



a



b



d

MALFUNCTIONS	CAUSES	SOLUTIONS
<p>Pump sputters or stops</p> <p>Pump stops, compressed air continuously escapes through the silencer</p>	<p>Impurities in the controller housing, excessive wear of controller parts, defective controller parts</p>	<p>▶ Check the complete controller</p> <p>Disassembly of the distributor:</p> <ul style="list-style-type: none">▶ Loosen the screws [1] by a maximum of 2 turns▶ Briefly apply compressed air to the pump to loosen the distributor▶ Remove the screws [1], the cage [2] and the silencer [3] and take off the complete distributor [4.1]▶ Check the complete distributor assembly [4.1 – 4.6] especially the O-rings [4.2, 4.3, 4.4], the face of the distributor [4.1] the valve plate [4.5] and the clamp [4.6]▶ In case of a defect, replace the complete assembly▶ During assembly, pay attention to the correct position and the correct seat of the valve plate [4.5] and the clamp [4.6] <p>Disassembly of the shift levers:</p> <ul style="list-style-type: none">▶ Loosen the screws [1.1] and remove the inserts [5] on both sides▶ Remove the compression springs [6.2], sleeves [6.3] and shift levers [6.4] of the controller housing [18]▶ Check the components for completeness (spalling, spring fracture)▶ In case of a defect, replace always the complete components on both sides▶ Before assembly, put at first the O-rings [6.1] into the controller housing [18] then position the control valve [12.3] in central position on the piston rod and put the shift levers [6.4] ; pre-assembled with sleeve [6.3] and compression spring [6.2] into the two grooves at the control valve [12.3]▶ Use the mounting aid (86896) to put the inserts [5] into the controller housing [18] and screw them down CLIP 3 <p>required tools: a/b/c/d</p>



- a Vice with soft jaws (not shown)
- b Screwdriver, cross-recess
- c Lockable compressed air connection
- d Needle-nose pliers



MALFUNCTIONS

Pump stops, compressed air continuously escapes through the silencer

CAUSES

Leaky piston unit, leaky O-ring in the controller housing, leaky O-ring in the controller housing

SOLUTIONS

- To do this, dismantle the complete control unit as described under 34
- Dismantle the complete high-pressure tube [28] and the piston rod [26]. To do this, put the pump in the mounting device (86 896) and loosen the high-pressure tube [28] from the connecting flange[21.1]
- Put the pump in the mounting device (86 897), and pull the high-pressure hose[28] back until the cross boring with the clamping sleeve [22] becomes visible in the piston rod [26]
- Now remove the clamping sleeve [22] and unscrew the high-pressure tube [28] and the piston rod [26] from the piston rod [12.4]
- Put the pump again in the mounting device (86 896) and remove the screws [19]
- At the piston rod's [12.4] wrench flat, the pump body can then be fixed in a vice (with clamping jaws with smooth surfaces)
- Now, take off the pressure cylinder [7] loosen the nut [9] and remove the washer [10], the piston unit [11] and the levelling washer [13] from the piston rod [12.2]
- Check the piston unit [11] for damage (voids, cracks) and wear
- In addition, check and if required replace the O-ring [12.1] on the piston rod [12.2]
- Remove the screws [14] and the washer [15] to check the O-ring [16] **CLIP 4**

required tools: **a/b/c/d/e/f/g/h/i/j**



- a** Vice with soft jaws (not shown)
- b** Screwdriver, cross-recess
- c** Lockable compressed air connection
- d** Needle-nose pliers
- e** Water pump pliers
- f** 2 x Pipe wrench
- g** Pin punch D3 and D5
- h** Hammer
- i** Allen key WAF 5
- j** Open-end wrench WAF 17
- k** Locking ring pliers, internal



PNEUMATIC GREASE PUMP 10:1

MALFUNCTIONS	CAUSES	SOLUTIONS
Oil/ grease escapes at the silencer	Condensed water/oil in the compressed air hose	▶ Empty the treatment unit / condensate separator, correctly adjust the oil mister CLIP 6
	Defective seal between pump and controller	▶ Proceed as described under point 34 and 35 ▶ Dismantle [21.3, 21.4, 21.5, 21.6 and 21.7] in the connecting flange [21.1]] ▶ Check the sealing ring [21.6] and the O-Ring [21.3] for damage or wear and replace them if required CLIP 5 required tools: a/b/c/d/e/f/g/h/i/j/k/l/m



- a** Vice with soft jaws (not shown)
- b** Screwdriver, cross-recess
- c** Lockable compressed air connection
- d** Needle-nose pliers
- e** Open-end wrench WAF 30
- f** Open-end wrench WAF 17
- g** Open-end wrench WAF 8
- h** Water pump pliers
- i** 2x Pipe wrench
- j** Pin punch D3 and D5
- k** Hammer
- l** Allen key WAF 5
- m** Locking ring pliers, internal



PNEUMATIC GREASE PUMP 10:1

SPARE PARTS LIST


1	Gefu self-tapping screw M 5x16	87220
1.1	Gefu self-tapping screw M 5x16	87220
2	Cage	87207
3	Silencer	87227
4.1	Distributor	87204
4.2	O-ring NBR 70-26 x 2	87223
4.3	O-ring NBR 70-24 x 2	87224
4.4	O-ring NBR 70-22 x 2	87225
4.5	Valve plate	87213
4.6	Clamp	87214
5	Insert	87206
6.1	O-ring NBR 70-26 x 2	87223
6.2	Compression spring	87215
6.3	Sleeve	87209
6.4	Shift lever	87210
7	Pressure cylinder	03268
8	O-ring NBR 70-81 x 1,5	03316
9	Nut DIN 985 M10	03311
10	Washer	87116
11	Piston unit NBR 70-80 x 22,5	03324
12.1	O-ring NBR 70-8 x 1	03262
12.2	Piston rod	87352
13	Levelling washer	03250
14	Gefu self-tapping screw M4 x 12	87221
15	Washer	87212
16	O-ring NBR 90-12 x 2	02380
17	O-ring NBR 70-8 x 1	03262
18	Controller housing	87211
19	Cylinder screw M5 x 80	87222
20	O-ring NBR 70-35 x 1,5	87226
21.1	Connecting flange 50:1	87216
21.2	Slide bearing	03307
21.3	O-ring NBR 90-12 x 2	02380
21.4	Washer	87262
21.5	Support washer	03292
21.6	Lip seal PU 93 20 x 12 x 5,7 mm	03387
21.7	Locking ring DIN 984-20 x 1	03264
22	Slotted spring pin ISO 8752	03260
23	Filter element	87228
24	Reducer	20122
25	Pressure reducing valve	04698
26	Piston rod	82814
27	O-ring 26.7x1.78 PU 90	87521
28	High-pressure tube	82827
29	Piston	82829
30	Turcon glyd ring	82881
31	Piston guide ring	82880
32	Compression spring, cyl. 0,8 x 10 x 20 x 3,5	82875

33	Steel ball, 16mm	82879
34	Valve screw	82874
35	Pump cylinder	82828
36	Valve cone	82872
37	Suction valve	82873
38	Slotted spring pin ISO 8752	84163

REPAIR KITS

Seal kit	72073
Piston rod	87352
Shift lever	72090
Distributor	87351

PNEUMATIC GREASE PUMP 15:1



PNEUMATIC GREASE PUMP 15:1

MALFUNCTIONS	CAUSES	SOLUTIONS
Pump runs, but does not deliver sufficiently grease.	Empty tank / container	<ul style="list-style-type: none">▶ Check and if required replace container CLIP 12
Pump continues to run when the shut-off nozzle is closed (individual strokes at longer intervals)	Pump sucks in air	<ul style="list-style-type: none">▶ Run the pump at a maximum pressure of 3 bar and loosen the pressure hose directly at the pump for venting▶ Press the follower plate down in the container until grease escapes from the center boring▶ Shake the container CLIP 12
	Suction fitting or strainer in the pump dirty	<ul style="list-style-type: none">▶ Check and clean the suction fitting [43] CLIP 13 <p>required tools: a/b</p>
	Defective / leaky suction valve in the pump cylinder	<ul style="list-style-type: none">▶ Check the sealing cone [39] and the lip seal [38] for damage or dirt and replace if required▶ To do this, dismantle [43, 42, 41, 40]▶ Check the interior sealing surface in the valve body [40] if damaged, replace part▶ Check the outside surface of the threaded rod [31] replace if damaged CLIP 13 <p>required tools: a/b/c/d/e/f/g</p>
	Leaky / defective valve in the pump piston	<ul style="list-style-type: none">▶ Check the valve. To do this, dismantle [43, 42, 41, 40, 39, 36, 34]▶ Pull the complete piston rod downwards by means of a mandrel in the cross boring of the piston[29]▶ Remove the clamping sleeve [27] and unscrew the piston [29] and the ball [28]▶ Clean and check the ball [28] and the ball seat in the piston [29] and replace them if required CLIP 13 <p>required tools: a/b/c/d/e/f/g</p>
	Leaky / defective sealing ring in the pump piston	<ul style="list-style-type: none">▶ Check the sealing ring, to do this dismantle [43, 42, 41, 40, 39, 36, 34]▶ Remove the sealing ring [35] from the adapter [34] clean and check it and replace it if required CLIP 13 <p>required tools: a/b/c/d/e/f/g</p>



- a Vice with soft jaws (not shown)
- b Open-end wrench WAF 30
- c Open-end wrench WAF 8
- d Water pump pliers
- e Locking ring pliers, internal
- f 2x Pipe wrench
- g Pin punch D3 and D6
- h Hammer



MALFUNCTIONS

CAUSES

SOLUTIONS

Pump does not start or runs only for a short time

Excessive counterpressure

- ▶ Open the delivery valve, hose cross-section too small, hose too long **CLIP 8**

Pump works, but pump runs slowly or stops

Excessive viscosity of the medium

- ▶ Maximum admissible degree of consistency NLGI 3 at 15°C **CLIP 8**

Not enough compressed air

- ▶ Ensure sufficient supply of compressed air (max. air consumption 400l/min)
- ▶ Dirty filter element [23]. For cleaning, remove the reducer [24] with pressure reducing valve [25] and compressed air connector **CLIP 2**

required tools: **a / b**

Uninsufficient pressure

- ▶ Ensure sufficient supply of compressed air (recommended air pressure 6 to 8 bar)
- ▶ Defective pressure reducing valve [25]. Replace the valve **CLIP 2**

required tools: **a / b**

Dirty / icy silencer

- ▶ Clean the silencer to do this, remove screws [1] and cage [2]
- ▶ Clean the silencer [3] with detergent and compressed air
- ▶ Use only lubricated compressed air (treatment unit with water separator and oil mister) **CLIP 2**

required tools: **c / d**



- a** Vice with soft jaws (not shown)
- b** Open-end wrench WAF 19
- c** Open-end wrench WAF 17
- d** Screwdriver, cross-recess



MALFUNCTIONS	CAUSES	SOLUTIONS
<p>Pump sputters or stops</p> <p>Pump stops, compressed air continuously escapes through the silencer</p>	<p>Impurities in the controller housing, excessive wear of controller parts, defective controller parts</p>	<p>► Check the complete controller</p> <p>Disassembly of the distributor:</p> <p>► Loosen the screws [1] by a maximum of 2 turns</p> <p>► Briefly apply compressed air to the pump to loosen the distributor</p> <p>► Remove the screws [1], the cage [2] and the silencer [3] and take off the complete distributor [4.1]</p> <p>► Check the complete distributor assembly [4.1 – 4.6] especially the O-rings [4.2, 4.3, 4.4], the face of the distributor [4.1] the valve plate [4.5] and the clamp [4.6]</p> <p>► In case of a defect, replace the complete assembly.</p> <p>► During assembly, pay attention to the correct position and the correct seat of the valve plate [4.5] and the clamp [4.6]</p> <p>Disassembly of the shift levers:</p> <p>► Loosen the screws [1.1] and remove the inserts [5] on both sides</p> <p>► Remove the compression springs [6.2], sleeves [6.3] and shift levers [6.4] of the controller housing [18]</p> <p>► Check the components for completeness (spalling, spring fracture.)</p> <p>► In case of a defect, replace always the complete components on both sides</p> <p>► Before assembly, put at first the O-rings [6.1] into the controller housing [18] then position the control valve [12.3] in central position on the piston rod and put the shift levers [6.4] pre-assembled with sleeve [6.3] and compression spring [6.2] into the two grooves at the control valve [12.3]</p> <p>► Use the mounting aid (86896) to put the inserts [5] into the controller housing [18] and screw them down CLIP 3</p> <p>required tools: a / b / c / d</p>



- a Vice with soft jaws (not shown)
- b Screwdriver, cross-recess
- c Lockable compressed air connection
- d Needle-nose pliers



MALFUNCTIONS

Pump stops, compressed air continuously escapes through the silencer

CAUSES

Leaky piston unit, leaky O-ring in the controller housing

SOLUTIONS

- ▶ To do this, dismantle the complete controller as described under 42
- ▶ Dismantle the complete pump unit, including the high-pressure tube and the piston rod
- ▶ To do this, remove the suction fitting [43], push the piston rod and the grease feeder [41] in the upper end position and dismantle it
- ▶ Dismantle then the valve body [40] and the valve cone [39]
- ▶ Put the pump in the mounting device (86 896) and loosen the high-pressure tube [33] from the connecting flange [21.1]
- ▶ Put the pump in the mounting device (86 897), pull the high-pressure tube [33] backwards until the cross boring with the clamping sleeve [22] becomes visible in the piston rod [26]
- ▶ Remove now the clamping sleeve [22] and unscrew the high-pressure tube [33] and the piston rod [26] from the piston rod [12.4]
- ▶ Put the pump again in the mounting device (86 896) and remove the screws [19]
- ▶ At the piston rod's [12.4] wrench flat, the pump body can then be fixed in a vice (with clamping jaws with smooth surfaces)
- ▶ Now, take off the pressure cylinder [7] loosen the nut [9] and remove the washer [10], the piston unit [11] and the levelling washer [13] from the piston rod [12.4]
- ▶ Check the piston unit [11] for damage (voids, cracks) and wear
- ▶ In addition, check and if required replace the O-ring [12.1] on the piston rod [12.2]
- ▶ Remove the screws [14] and the washer [15] to check the O-ring [16] **CLIP 4**

required tools: **a/b/c/d/e/f/g/h/i/j/k/l**



- a** Vice with soft jaws (not shown)
- b** Screwdriver, cross-recess
- c** Lockable compressed air connection
- d** Needle-nose pliers
- e** Gabelschlüssel SW 30
- f** Open-end wrench WAF 17
- g** Open-end wrench WAF 8
- h** Water pump pliers
- i** 2 x Pipe wrench
- j** Pin punch D3 and D5
- k** Hammer
- l** Allen key WAF 5



MALFUNCTIONS

CAUSES

SOLUTIONS

Oil escapes at the silencer

Condensed water/oil in the compressed air hose

- ▶ Empty the treatment unit / condensate separator, correctly adjust the oil mister **CLIP 6**

Defective seal between pump and controller

- ▶ Proceed as described under page 42 and 43.
- ▶ Dismantle [21.3, 21.4, 21.5, 21.6 and 21.7] in the connecting flange [21.1]
- ▶ Check the sealing ring [21.6] and the O-ring [21.3] for damage or wear and replace them if required **CLIP 5**

required tools: **a/b/c/d/e/f/g/h/i/j/k/l/m**



- a** Vice with soft jaws (not shown)
- b** Screwdriver, cross-recess
- c** Lockable compressed air connection
- d** Needle-nose pliers
- e** Open-end wrench WAF 30
- f** Open-end wrench WAF 17
- g** Open-end wrench WAF 8
- h** Water pump pliers
- i** 2x Pipe wrench
- j** Pin punch D3 and D5
- k** Hammer
- l** Allen key WAF 5
- m** Locking ring pliers, internal



PNEUMATIC GREASE PUMP 15:1

SPARE PARTS LIST


1	Gefu self-tapping screw M 5x16	87220
1.1	Gefu self-tapping screw M 5x16	87220
2	Cage	87207
3	Silencer	87227
4.1	Distributor	87204
4.2	O-ring NBR 70-26 x 2	87223
4.3	O-ring NBR 70-24 x 2	87224
4.4	O-ring NBR 70-22 x 2	87225
4.5	Valve plate	87213
4.6	Clamp	87214
5	Insert	87206
6.1	O-ring NBR 70-26 x 2	87223
6.2	Compression spring	87215
6.3	Sleeve	87209
6.4	Shift lever	87210
7	Pressure cylinder	03268
8	O-ring NBR 70-81 x 1,5	03316
9	Nut DIN 985 M10	03311
10	Washer	87116
11	Piston unit NBR 70-80 x 22,5	03324
12.1	O-ring NBR 70-8 x 1	03262
12.2	Piston rod	87352
13	Levelling washer	03250
14	Gefu self-tapping screw M4 x 12	87221
15	Washer	87212
16	O-ring NBR 90-12 x 2	02380
17	O-ring NBR 70-8 x 1	03262
18	Controller housing	87211
19	Cylinder screw M5 x 80	87222
20	O-ring NBR 70-35 x 1,5	87226
21.1	Connecting flange 50:1	87216
21.2	Slide bearing	03307
21.3	O-ring NBR 90-12 x 2	02380
21.4	Washer	87262
21.5	Support washer	03292
21.6	Lip seal PU 93 20 x 12 x 5,7 mm	03387
21.7	Locking ring DIN 984-20 x 1	03264
22	Slotted spring pin ISO 8752	03260
23	Filter element	87228
24	Reducer	20122
25	Pressure reducing valve	04698
26	Piston rod	87518
27	Slotted spring pin	03260
28	Steel ball, D = 6 mm	03304
29	Pressure piston	82481
30	Nut DIN 934	00808
31	Threaded rod	87509
32	O-ring 26.7x1.78 PU 90	87521

33	High-pressure tube	87513
34	Adapter for grease pump	82480
35	Rod seal-PU 90	03317
36	Pressure cylinder	82479
37	Locking ring	03501
38	Lip seal PU93	00152
39	Valve cone	03477
40	Valve body	82482
41	Grease feeder	87528
42	Nut DIN 985	01085
43	Suction fitting	87504

REPAIR KITS

Seal kit	72074
Piston rod	87352
Shift lever	72090
Distributor	87351

PNEUMATIC GREASE PUMP 50:1



MALFUNCTIONS	CAUSES	SOLUTIONS
Pump runs, but does not deliver sufficiently grease	Empty tank / container	<ul style="list-style-type: none">▶ Check and if required replace container CLIP 12
Pump continues to run when the shut-off nozzle is closed (individual strokes at longer intervals)	Trapped air in the container or in the pump	<ul style="list-style-type: none">▶ Run the pump at a maximum pressure of 3 bar and loosen the pressure hose directly at the pump for venting▶ Press the follower plate down in the container until grease escapes from the center boring▶ Shake the container CLIP 12
	Suction fitting or strainer in the pump dirty	<ul style="list-style-type: none">▶ Check and clean the suction fitting [45]▶ Check and clean the strainer [41] to do this dismantle [45, 44, 43, 42] CLIP 13 <p>required tools: a/b/c/d/e</p>
	Leaky / defective suction valve in the pump piston	<ul style="list-style-type: none">▶ Check the sealing cone [39] and the lip seal [38] for damage or dirt and replace if required▶ To do this, dismantle [45, 44, 43, 40]▶ Check the interior sealing surface [40] if damaged replace the part▶ Check the outside surface of the threaded rod [31] replace if damaged CLIP 13 <p>required tools: a/b/c/d/e/f/g/h</p>
	Leaky / defective valve in the pump piston	<ul style="list-style-type: none">▶ Check the valve, to do this, dismantle [45, 44, 43, 40, 39, 36, 34]▶ Pull the complete piston rod downwards by means of a mandrel in the cross boring of the piston [29]▶ Remove the clamping sleeve [27] and unscrew the piston [29] and the ball [28]▶ Clean and check the ball [28] and the ball seat in the piston [29] and replace it if required CLIP 13 <p>required tools: a/b/c/d/e/f/g/h</p>
	Leaky / defective sealing ring in the pump piston	<ul style="list-style-type: none">▶ Check the sealing ring, to do this, dismantle [45, 44, 43, 40, 39, 36, 34]▶ Loosen the sealing ring [35] from the adapter [34] clean and replace it if required CLIP 13 <p>required tools: a/b/c/d/e/f/g/h</p>



- a Vice with soft jaws (not shown)
- b Gabelschlüssel SW 30
- c Open-end wrench WAF 8
- d Water pump pliers
- e 2 x Locking ring pliers, internal
- f 2 x Pipe wrench
- g Pin punch D3 and D5
- h Hammer



MALFUNCTIONS

CAUSES

SOLUTIONS

Pump does not start or runs only for a short time

Excessive counterpressure

- ▶ Open the delivery valve, hose cross-section too small, hose too long [CLIP 8](#)

Pump works, pump runs slowly or stops

Excessive viscosity of the medium

- ▶ Maximum admissible degree of consistency NLGI 2 at 15°C [CLIP 9](#)

Not enough compressed air

- ▶ Ensure sufficient supply of compressed air (max. air consumption 400 l/min)
- ▶ Dirty filter element [23]. For cleaning, remove the reducer [24] with pressure reducing valve [25] and compressed air connector [CLIP 2](#)

required tools: **a / b**

Uninsufficient pressure

- ▶ Ensure sufficient supply of compressed air (recommended air pressure 6 to 8 bar)
- ▶ Defective pressure reducing valve [25] . Replace the valve [CLIP 2](#)

required tools: **a / b**

Dirty / icy silencer

- ▶ Clean the silencer, to do this, remove the screws [1] and the cage [2]
- ▶ Clean the silencer [3] with detergent and compressed air
- ▶ Use only lubricated compressed air (treatment unit with water separator and oil mister) [CLIP 2](#)

required tools: **c / d**



- a** Open-end wrench WAF 19
- b** Open-end wrench WAF 17
- c** Vice with soft jaws (not shown)
- d** Screwdriver, cross-recess



MALFUNCTIONS	CAUSES	SOLUTIONS
<p>Pump sputters or stops</p> <p>Pump stops, compressed air continuously escapes through the silencer</p>	<p>Impurities in the controller housing, excessive wear of controller parts, defective controller parts</p>	<p>▶ Check the complete controller</p> <p>Disassembly of the distributor:</p> <ul style="list-style-type: none">▶ Loosen the screws [1] by a maximum of 2 turns▶ Briefly apply compressed air to the pump to loosen the distributor▶ Remove the screws [1] the cage [2] and the silencer [3] and take off the complete distributor [4.1]▶ Check the complete distributor assembly [4.1 – 4.6] especially the O-rings [4.2, 4.3, 4.4], the face of the distributor [4.1] the valve plate [4.5] and the clamp [4.6]▶ In case of a defect, replace the complete assembly.▶ During assembly, pay attention to the correct position and the correct seat of the valve plate [4.5] and the clamp [4.6] <p>Disassembly of the shift levers:</p> <ul style="list-style-type: none">▶ Loosen the screws [1.1] and remove the inserts [5] on both sides▶ Remove the compression springs [6.2], sleeves [6.3] and shift levers [6.4] of the controller housing [18]▶ Check the components for completeness (spalling, spring fracture)▶ In case of a defect, replace always the complete components on both sides▶ Before assembly, put at first the O-rings [6.1] into the controller housing [18] then position the control valve [12.3] in central position on the piston rod and put the shift levers [6.4] pre-assembled with sleeve [6.3] and compression spring [6.2] into the two grooves at the control valve [12.3]▶ Use the mounting aid (86896) to put the inserts [5] into the controller housing [18] and screw them down CLIP 3 <p>required tools: a / b / c / d</p>



- a Vice with soft jaws (not shown)
- b Screwdriver, cross-recess
- c Lockable compressed air connection
- d Needle-nose pliers



MALFUNCTIONS

Pump stops, compressed air continuously escapes through the silencer

CAUSES

Leaky piston unit, leaky O-ring in the controller housing

SOLUTIONS

- ▶ To do this, dismantle the complete control unit as described under 50
- ▶ Dismantle the complete pump unit, including the high-pressure tube and the piston rod
- ▶ To do this, remove the suction fitting [45], push the piston rod and the grease feeder [43] in the upper end position and dismantle it.
- ▶ Dismantle then the valve body [40] and the valve cone [39]
- ▶ Put the pump in the mounting device (86 896) and loosen the high-pressure tube [33] from the connecting flange [21.2]
- ▶ Put the pump in the mounting device (86 897), pull the high-pressure tube [33] back until the cross boring with the clamping sleeve [22] becomes visible in the piston rod [26]
- ▶ Remove now the clamping sleeve [22] and unscrew the high-pressure tube [33] and piston rod [26] from the piston rod [12.4]
- ▶ Put the pump again in the mounting device (86 896) and remove the screws [19]
- ▶ At the piston rod's [12.4] wrench flat, the pump body can then be fixed in a vice (with clamping jaws with smooth surfaces)
- ▶ Now, take off the pressure cylinder [7] loosen the nut [9] and remove the washer [10], the piston unit [11] and the levelling washer [13] from the piston rod [12.4]
- ▶ Check the piston unit [11] for damage (voids, cracks) and wear
- ▶ In addition, check and if required replace the O-ring [12.1] on the piston rod [12.2]
- ▶ Remove the screws [14] and the washer [15] to check the O-ring [16] **CLIP 4**

required tools: **a/b/c/d/e/f/g/h/i/j/k/l**



- a** Vice with soft jaws (not shown)
- b** Screwdriver, cross-recess
- c** Lockable compressed air connection
- d** Needle-nose pliers
- e** Open-end wrench WAF 30
- f** Open-end wrench WAF 17
- g** Open-end wrench WAF 8
- h** Water pump pliers
- i** 2 x Pipe wrench
- j** Pin punch D3 and D5
- k** Hammer
- l** Allen key WAF 5



PNEUMATIC GREASE PUMP 50:1

MALFUNCTIONS

Oil / grease escapes at the
silencer

CAUSES

Condensed water/oil in the
compressed air hose

Defective seal between
pump and controller

SOLUTIONS

- ▶ Empty the treatment unit / condensate separator, correctly adjust the oil mister. **CLIP 6**
- ▶ Proceed as described under point 50 and 51
- ▶ Dismantle [21.3, 21.4, 21.5, 21.6 and 21.7] in the connecting flange [21.1]
- ▶ Check the sealing ring [21.6] and the O-ring [21.3] for damage or wear and replace them if required **CLIP 5**

required tools: **a/b/c/d/e/f/g/h/i/j/k/l/m**



- a** Vice with soft jaws (not shown)
- b** Screwdriver, cross-recess
- c** Lockable compressed air connection
- d** Needle-nose pliers
- e** Open-end wrench WAF 30
- f** Open-end wrench WAF 17
- g** Open-end wrench WAF 8
- h** Water pump pliers
- i** 2 x Pipe wrench
- j** Pin punch D3 and D5
- k** Hammer
- l** Allen key WAF 5
- m** Locking ring pliers, internal



PNEUMATIC GREASE PUMP 50:1

SPARE PARTS LIST

1	Gefu self-tapping screw M 5x16	87220	31	Threaded rod	87509
1.1	Gefu self-tapping screw M 5x16	87220	32	O-ring 26.7 x 1.78 PU 90	87521
2	Cage	87207	33	High-pressure tube	87511
3	Silencer	87227	34	Adapter	87507
4.1	Distributor	87204	35	Rod seal-24 x 16 x 5,7-PU93	87522
4.2	O-ring NBR 70-26 x 2	87223	36	Pressure cylinder	87506
4.3	O-ring NBR 70-24 x 2	87224	37	Locking ring bore hole 13 x 1	03501
4.4	O-ring NBR 70-22 x 2	87225	38	Lip seal PU93	00152
4.5	Valve plate	87213	39	Valve cone	03477
4.6	Clamp	87214	40	Valve body	87505
5	Insert	87206	41	Strainer	03503
6.1	O-ring NBR 70-26 x 2	87223	42	Locking ring	03328
6.2	Compression spring	87215	43	Grease feeder	87528
6.3	Sleeve	87209	44	Nut DIN 985	01085
6.4	Shift lever	87210	45	Suction fitting	87504
7	Pressure cylinder	03268			
8	O-ring NBR 70-81 x 1,5	03316			
9	Nut DIN 985 M10	03311			
10	Washer	87116			
11	Piston unit NBR 70-80 x 22,5	03324			
12.1	O-ring NBR 70-8 x 1	03262			
12.2	Piston rod	87352			
13	Levelling washer	03250			
14	Gefu self-tapping screw M4 x 12	87221			
15	Washer	87212			
16	O-ring NBR 90-12 x 2	02380			
17	O-ring NBR 70-8 x 1	03262			
18	Controller housing	87211			
19	Cylinder screw M5 x 80	87222			
20	O-ring NBR 70-35 x 1,5	87226			
21.1	Connecting flange 50:1	87216			
21.2	Slide bearing	03307			
21.3	O-ring NBR 90-12 x 2	02380			
21.4	Washer	87262			
21.5	Support washer	03292			
21.6	Lip seal PU 93 20 x 12 x 5,7 mm	03387			
21.7	Locking ring DIN 984-20 x 1	03264			
22	Slotted spring pin ISO 8752	03260			
23	Filter element	87228			
24	Reducer	20122			
25	Pressure reducing valve	04698			
26	Piston rod	87516			
27	Slotted spring pin ISO 8752	03260			
28	Steel ball, D=6 mm	03304			
29	Pressure piston	87508			
30	Nut DIN 934	00808			

REPAIR KITS

Seal kit	72075
Piston rod	87352
Shift lever	72090
Distributor	87351

REPAIR KITS PARTS LIST

Pneumatic oil and diesel pump 1:1	Seal kit 72070		Piston rod 87354	Shift lever 72090	Distributor 87351
	03262	87224	03262	87210	87204
	03324	02380	87205	87209	87223
	87225	88164	87208	87215	87224
	03316	88165	02841	87223	87225
	87223	03389			87213
	87226	02850			87214
	03338				
Pneumatic radiator antifreeze pump 1:1			Piston rod 87354	Shift lever 72090	Distributor 87351
			03262	87210	87204
			87205	87209	87223
			87208	87215	87224
			02841	87223	87225
					87213
					87214
Pneumatic oil pump 3:1	Seal kit 72071		Piston rod 87353	Shift lever 72090	Distributor 87351
	03262	02380	03262	87210	87204
	03324	03387	87205	87209	87223
	87225	03390	87208	87215	87224
	03316	02849	02843	87223	87225
	87223	88164			87213
	87226	88165			87214
	87224	87521			
Pneumatic oil pump 5:1	Seal kit 72072		Piston rod 87655	Shift lever 72090	Distributor 87351
	03262	02380	03262	87210	87204
	03324	88164	87205	87209	87223
	87225	88165	87208	87215	87224
	03316	03387	87633	87223	87225
	87223	87629			87213
	87226	87632			87214
	87521	03390			
	87224				

REPAIR KITS PARTS LIST

Pneumatic grease pump 10:1	Seal kit 72073		Piston rod 87352	Shift lever 72090	Distributor 87351
	87521	87225	03262	87210	87204
	03316	87224	87205	87209	87223
	03324	03262	87208	87215	87224
	02380	87226	02840	87223	87225
	87223	03387			87213 87214
Pneumatic grease pump 15:1	Seal kit 72074		Piston rod 87352	Shift lever 72090	Distributor 87351
	87521	87223	03262	87210	87204
	03317	87225	87205	87209	87223
	00152	87224	87208	87215	87224
	03316	03262	02840	87223	87225
	03324	87226			87213 87214
	02380	03387			
Pneumatic grease pump 50:1	Seal kit 72075		Piston rod 87352	Shift lever 72090	Distributor 87351
	03262	87224	03262	87210	87204
	03324	02380	87205	87209	87223
	87225	03387	87208	87215	87224
	03316	87521	02840	87223	87225
	87223	87522			87213 87214
	87226	00152			

Pressol Schmiergeräte GmbH

Parkstraße 7

93167 Falkenstein | Germany


Phone +49 9462 17-0

Telefax +49 9462 17-208

info@pressol.com

www.pressol.com

PNEUMATIC OIL
AND DIESEL PUMP 1:1



SPARE PARTS LIST



1	Gefu self-tapping screw M 5x16	87220	24	Reducer	20122
2	Cage	87207	25	Pressure reducing valve	04698
3	Silencer	87227	26	Washer, curved	03509
4.1	Distributor	87204	27	Compression spring	02851
4.2	O-ring NBR 70-26 x 2	87223	28	Washer	03507
4.3	O-ring NBR 70-24 x 2	87224	29	Valve plate	03410
4.4	O-ring NBR 70-22 x 2	87225	30	Pump piston	02847
4.5	Valve plate	87213	31	Nut	03415
4.6	Clamp	87214	32	Lip seal NBR 84 80 x 68 x 8,5mm	03389
5	Insert	87206	33	Nut	01085
6.1	O-ring NBR 70-26 x 2	87223	34	Valve plate	03417
6.2	Compression spring	87215	35	O-ring NBR 70-82 x 2,5	02850
6.3	Sleeve	87209	36	Pump cylinder	02855
6.4	Shift lever	87210	37	Valve rod	03336
7	Pressure cylinder	03268	38	Compression spring	02852
8	O-ring NBR 70-81 x 1,5	03316	39	Washer	02853
9	Nut DIN 985-M10	03311			
10	Washer	87116			
11	Piston unit NBR 70-80 x 22,5	03324			
12.1	O-ring NBR 70-8 x 1	03262			
12.2	Piston rod	87354			
13	Levelling washer	03250			
14	Gefu self-tapping screw M4 x 12	87221			
15	Washer	87212			
16	O-ring NBR 90-12 x 2	02380			
17	O-ring NBR 70-8 x 1	03262			
18	Controller housing	87211			
19	Cylinder screw M 5x80	87222			
20	O-ring NBR 70-35 x 1,5	87226			
21	Connecting flange	87218			
22.1	O-ring NBR 90-12 x 2	02380			
22.2	O-ring NBR 70-14 x 1,78	88164			
22.3	O-ring NBR 70-19 x 1,5	88165			
22.4	Adapter	88152			
22.5	Lip seal NBR 72-20 x 12 x 5,5	03338			
22.6	Locking ring DIN 984-20 x 1	03264			
23	Filter element	87228			

REPAIR KITS

Seal kit	72070
Piston rod	87354
Shift lever	72090
Distributor	87351



PNEUMATIC
RADIATOR ANTIFREEZE
PUMP 1:1



SPARE PARTS LIST



1	Gefu self-tapping screw M 5x16	87220	23	Filter element	87228
1.1	Gefu self-tapping screw M 5x16	87220	24	Reducer	20122
2	Cage	87207	25	Pressure reducing valve	04698
3	Silencer	87227	26	Washer, curved	03509
4.1	Distributor	87204	27	Compression spring	02851
4.2	O-ring NBR 70-26 x 2	87223	28	Washer	03507
4.3	O-ring NBR 70-24 x 2	87224	29	Valve plate 60 x 10,6 mm	03410
4.4	O-ring NBR 70-22 x 2	87225	30	Pump piston	02847
4.5	Valve plate	87213	31	Nut	03415
4.6	Clamp	87214	32	Piston seal 80 x 68 x 8,5	87792
5	Insert	87206	33	Nut	01085
6.1	O-ring NBR 70-26 2	87223	34	Valve plate	03417
6.2	Compression spring	87215	35	O-ring NBR 70-82 x 2,5	02850
6.3	Sleeve	87209	36	Pump cylinder	87790
6.4	Shift lever	87210	37	Valve rod	03336
7	Pressure cylinder	03268	38	Compression spring	02852
8	O-ring NBR 70-81 1,5	03316	39	Washer	02853
9	Nut DIN 985-M10	03311			
10	Washer	87116			
11	Piston unit NBR 70-80 x 22,5	03324			
12.1	O-ring NBR 70-8 x 1	03262			
12.2	Piston rod	87354			
13	Levelling washer	03250			
14	Gefu self-tapping screw M4 x 12	87221			
15	Washer	87212			
16	O-ring NBR 90-12 x 2	02380			
17	O-ring NBR 70-8 x 1	03262			
18	Controller housing	87211			
19	Cylinder screw M5 x 80	87222			
20	O-ring NBR 70-35 x 1,5	87226			
21	Connecting flange	87218			
22.1	O-ring NBR 90-12 x 2	02380			
22.2	O-ring NBR 70-14 x 1,78	88164			
22.3	O-ring NBR 70-19 x 1,5	88165			
22.4	Adapter	88152			
22.5	Rod seal 12 x 20 x 5,5	87791			
22.6	Locking ring DIN 984-20 x 1	03264			

REPAIR KITS

Piston rod	87354
Shift lever	72090
Distributor	87351



PNEUMATIC OIL PUMP 3:1



SPARE PARTS LIST



1	Gefu self-tapping screw M 5x16	87220	23	Filter element	87228
1.1	Gefu self-tapping screw M 5x16	87220	24	Reducer	20122
2	Cage	87207	25	Pressure reducing valve	04698
3	Silencer	87227	26	Slotted spring pin DIN 1481	87630
4.1	Distributor	87204	27	Pump piston	02844
4.2	O-ring NBR 70-26 x 2	87223	28	Compression spring	02851
4.3	O-ring NBR 70-24 x 2	87224	29	Steel ball, D= 17 mm	03263
4.4	O-ring NBR 70-22 x 2	87225	30	O-ring 26.7 x 1.78 PU 90	87521
4.5	Valve plate	87213	31	Screw WAF 32	87646
4.6	Clamp	87214	32	Lip seal NBR 84-48 x 40x5,5	03390
5	Insert	87206	33	O-ring NBR 70-53 x 2	02849
6.1	O-ring NBR 70-26 x 2	87223	34	Nut DIN 985	01085
6.2	Compression spring	87215	35	Valve plate	03416
6.3	Sleeve	87209	36	Pump cylinder	02854
6.4	Shift lever	87210	37	Valve rod	03336
7	Pressure cylinder	03268	38	Compression spring	02852
8	O-ring NBR 70-81 x 1,5	03316	39	Washer	02853
9	Nut DIN 985-M10	03311			
10	Washer	87116			
11	Piston unit NBR 70-80 x 22,5	03324			
12.1	O-ring NBR 70-8 x 1	03262			
12.2	Piston rod	87353			
13	Levelling washer	03250			
14	Gefu self-tapping screw M4 x 12	87221			
15	Washer	87212			
16	O-ring NBR 90-12 x 2	02380			
17	O-ring NBR 70-8 x 1	03262			
18	Controller housing	87211			
19	Cylinder screw M5 x 80	87222			
20	O-ring NBR 70-35 x 1,5	87226			
21	Connecting flange	87217			
22.1	O-ring NBR 90-12 x 2	02380			
22.2	O-ring NBR 70-14 x 1,78	88164			
22.3	O-ring NBR 70-19 x 1,5	88165			
22.4	Adapter	88152			
22.5	Lip seal PU 93 20 x 12 x 5,7 mm	03387			
22.6	Locking ring DIN 984-20 x 1	03264			

REPAIR KITS

Seal kit	72071
Piston rod	87353
Shift lever	72090
Distributor	87351



PNEUMATIC OIL
PUMP 5:1



SPARE PARTS LIST



1	Gefu self-tapping screw M 5x16	87220	25	Pressure reducing valve	04698
1.1	Gefu self-tapping screw M 5x16	87220	26	Support washer	87648
2	Cage	87207	27	Lip seal NBR 90 44 x 34 x 7 mm	87632
3	Silencer	87227	28	Locking ring	87634
4.1	Distributor	87204	29.1	Piston tube	88168
4.2	O-ring NBR 70-26 x 2	87223	29.2	Stop plate	88113
4.3	O-ring NBR 70-24 x 2	87224	29.3	Lip seal PU 93 20 x 12 x 5,7 mm	03387
4.4	O-ring NBR 70-22 x 2	87225	29.4	O-ring 26.7x1.78 PU 90	87521
4.5	Valve plate	87213	29.5	Double piston	87645
4.6	Clamp	87214	30	Slotted spring pin DIN 1481	87630
5	Insert	87206	31	Compression spring	02851
6.1	O-ring NBR 70-26 x 2	87223	32	Steel ball, D = 17 mm	03263
6.2	Compression spring	87215	33	O-ring 26.7x1.78 PU 90	87521
6.3	Sleeve	87209	34	Screw	87646
6.4	Shift lever	87210	35	Lip seal NBR 84-48 x 40 x 5,5	03390
7	Pressure cylinder	03268	36	Locking ring	03328
8	O-ring NBR 70-81 x 1,5	03316	37	Locking pin	87746
9	Nut DIN 985-M10	03311	38	O-ring NBR 70	87629
10	Washer	87116	39	Steel ball, D = 19,05 mm	87631
11	Piston unit NBR 70-80 x 22,5	03324	40	Pump cylinder	87643
12.1	O-ring NBR 70-8 x 1	03262			
12.2	Piston rod	87655			
13	Levelling washer	03250			
14	Gefu self-tapping screw M4 x 12	87221			
15	Washer	87212			
16	O-ring NBR 90-12 x 2	02380			
17	O-ring NBR 70-8 x 1	03262			
18	Controller housing	87211			
19	Cylinder screw M5 x 80	87222			
20	O-ring NBR 70-35 x 1,5	87226			
21	Connecting flange 5:1	87642			
22.1	O-ring NBR 90-12 x 2	02380			
22.2	O-ring NBR 70-14 x 1,78	88164			
22.3	O-ring NBR 70-19 x 1,5	88165			
22.4	Adapter	88152			
22.5	Lip seal PU 93 20 x 12 x 5,7 mm	03387			
22.6	Locking ring DIN 984-20 x 1	03264			
23	Filter element	87228			
24	Reducer	20122			

REPAIR KITS

Seal kit	72072
Piston rod	87655
Shift lever	72090
Distributor	87351



PNEUMATIC GREASE PUMP 10:1




SPARE PARTS LIST

1	Gefu self-tapping screw M 5x16	87220	21.7	Locking ring DIN 984-20 x 1	03260
1.1	Gefu self-tapping screw M 5x16	87220	22	Slotted spring pin ISO 8752	03260
2	Cage	87207	23	Filter element	87228
3	Silencer	87227	24	Reducer	20122
4.1	Distributor	87204	25	Pressure reducing valve	04698
4.2	O-ring NBR 70-26 x 2	87223	26	Piston rod	82814
4.3	O-ring NBR 70-24 x 2	87224	27	O-Ring 26,7x1.78 PU 90	87521
4.4	O-ring NBR 70-22 x 2	87225	28	High-pressure tube	82827
4.5	Valve plate	87213	29	Piston	82829
4.6	Clamp	87214	30	Turcon Glyd Ring	82881
5	Insert	87206	31	Piston guide ring	82880
6.1	O-ring NBR 70-26 x 2	87223	32	Compression spring cylindrical	82875
6.2	Compression spring	87215	33	Steel ball, 16mm	82879
6.3	Sleeve	87209	34	Valve screw	82874
6.4	Shift lever	87210	35	Pump cylinder	82828
7	Pressure cylinder	03268	36	Valve cone	82872
8	O-ring NBR 70-81 x 1,5	03316	37	Suction valve	82873
9	Nut DIN 985-M10	03311	38	Slotted spring pin ISO 8752	84163
10	Washer	87116			
11	Piston unit NBR 70-80 x 22,5	03324			
12.1	O-ring NBR 70-8 x 1	03262			
12.2	Piston rod	87352			
13	Levelling washer	03250			
14	Gefu self-tapping screw M4 x 12	87221			
15	Washer	87212			
16	O-ring NBR 90-12 x 2	02380			
17	O-ring NBR 70-8 x 1	03262			
18	Controller housing	87211			
19	Cylinder screw M5 x 80	87222			
20	O-ring NBR 70-35 x 1,5	87226			
21.1	Connecting flange 50:1	87216			
21.2	Slide bearing	03307			
21.3	O-ring NBR 90-12 x 2	02380			
21.4	Washer	87262			
21.5	Support washer	03292			
21.6	Lip seal PU 93 20 x 12 x 5,7 mm	03387			

REPAIR KITS

Seal kit	72073
Piston rod	87352
Shift lever	72090
Distributor	87351





REPAIR KITS

Seal kit	72073
Piston rod	87352
Shift lever	72090
Distributor	87351

PRESSOL

PNEUMATIC GREASE PUMP 15:1



SPARE PARTS LIST


1	Gefu self-tapping screw M 5x16	87220	23	Filter element	87228
1.1	Gefu self-tapping screw M 5x16	87220	24	Reducer	20122
2	Cage	87207	25	Pressure reducing valve	04698
3	Silencer	87227	26	Piston rod	87518
4.1	Distributor	87204	27	Slotted spring pin	03260
4.2	O-ring NBR 70-26 x 2	87223	28	Steel ball, D=6 mm	03304
4.3	O-ring NBR 70-24 x 2	87224	29	Plunger	82481
4.4	O-ring NBR 70-22 x 2	87225	30	Nut DIN 934	00808
4.5	Valve plate	87213	31	Threaded rod	87509
4.6	Clamp	87214	32	O-ring 26.7x1.78 PU 90	87521
5	Insert	87206	33	High-pressure tube	87513
6.1	O-ring NBR 70-26 x 2	87223	34	Adapter for grease pump	82480
6.2	Compression spring	87215	35	Rod seal-PU 90	03317
6.3	Sleeve	87209	36	Pressure cylinder	82479
6.4	Shift lever	87210	37	Locking ring	03501
7	Pressure cylinder	03268	38	Lip seal PU93	00152
8	O-ring NBR 70-81 x 1,5	03316	39	Valve cone	03477
9	Nut DIN 985-M10	03311	40	Valve body	82482
10	Washer	87116	41	Grease feeder	87528
11	Piston unit NBR 70-80 x 22,5	03324	42	Nut DIN 985	01085
12.1	O-ring NBR 70-8 x 1	03262	43	Suction fitting	87504
12.2	Piston rod	87352			
13	Levelling washer	03250			
14	Gefu self-tapping screw M4 x 12	87221			
15	Washer	87212			
16	O-ring NBR 90-12 x 2	02380			
17	O-ring NBR 70-8 x 1	03262			
18	Controller housing	87211			
19	Cylinder screw M5 x 80	87222			
20	O-ring NBR 70-35 x 1,5	87226			
21.1	Connecting flange 50:1	87216			
21.2	Slide bearing	03307			
21.3	O-ring NBR 90-12 x 2	02380			
21.4	Washer	87262			
21.5	Support washer	03292			
21.6	Lip seal PU 93 20 x 12 x 5,7 mm	03387			
21.7	Locking ring DIN 984-20 x 1	03264			
22	Slotted spring pin ISO 8752	03260			

REPAIR KITS

Seal kit	72074
Piston rod	87352
Shift lever	72090
Distributor	87351



PNEUMATIC GREASE PUMP 50:1



SPARE PARTS LIST

1	Gefu self-tapping screw M 5x16	87220	25	Pressure reducing valve	04698
1.1	Gefu self-tapping screw M 5x16	87220	26	Piston rod	87516
2	Cage	87207	27	Slotted spring pin ISO 8752	03260
3	Silencer	87227	28	Steel ball, D = 6 mm	03304
4.1	Distributor	87204	29	Plunger	87508
4.2	O-ring NBR 70-26 x 2	87223	30	Nut DIN 934	00808
4.3	O-ring NBR 70-24 x 2	87224	31	Threaded rod	87509
4.4	O-ring NBR 70-22 x 2	87225	32	O-ring 26,7 x 1,78 PU 90	87521
4.5	Valve plate	87213	33	High-pressure tube	87511
4.6	Clamp	87214	34	Adapter	87507
5	Insert	87206	35	Rod seal-24 x 16 x 5,7-PU93	87522
6.1	O-ring NBR 70-26 x 2	87223	36	Pressure cylinder	87506
6.2	Compression spring	87215	37	Locking ring 13 x 1	03501
6.3	Sleeve	87209	38	Lip seal PU93	00152
6.4	Shift lever	87210	39	Valve cone	03477
7	Pressure cylinder	03268	40	Valve body	87505
8	O-ring NBR 70-81 x 1,5	03316	41	Strainer	03503
9	Nut DIN 985-M10	03311	42	Locking ring	03328
10	Washer	87116	43	Grease feeder	87528
11	Piston unit NBR 70-80 x 22,5	03324	44	Nut DIN 985	01085
12.1	O-ring NBR 70-8 x 1	03262	45	Suction fitting	87504
12.2	Piston rod	87352			
13	Levelling washer	03250			
14	Gefu self-tapping screw M4 x 12	87221			
15	Washer	87212			
16	O-ring NBR 90-12 x 2	02380			
17	O-ring NBR 70-8 x 1	03262			
18	Controller housing	87211			
19	Cylinder screw M5 x 80	87222			
20	O-ring NBR 70-35 x 1,5	87226			
21.1	Connecting flange 50:1	87216			
21.2	Slide bearing	03307			
21.3	O-ring NBR 90-12 x 2	02380			
21.4	Washer	87262			
21.5	Support washer	03292			
21.6	Lip seal PU 93 20 x 12 x 5,7 mm	03387			
21.7	Locking ring DIN 984-20 x 1	03264			
22	Slotted spring pin ISO 8752	03260			
23	Filter element	87228			
24	Reducer	20122			

REPAIR KITS

Seal kit	72075
Piston rod	87352
Shift lever	72090
Distributor	87351



REPAIR KITS

Seal kit	72075
Piston rod	87352
Shift lever	72090
Distributor	87351

